
BRINLY BH 16



OWNER'S MANUAL



STS-30 BH

SWEEPER

MODEL - STS-300 BH

"IMPORTANT: THIS MANUAL CONTAINS INFORMATION FOR THE SAFETY OF PERSONS AND PROPERTY. READ IT CAREFULLY BEFORE ASSEMBLY AND OPERATION OF THE EQUIPMENT!"

LIMITED WARRANTY


Brinly-Hardy Company warrants only to the orginal retail purchaser that this product will remain free of defects in workmanship and materials under normal use and service for a period of two (2) years (NOTE: ninety (90) days for commercial or rental use) commencing with the date of purchase.

Any parts found to be defective within the warranty period will be replaced, with proof of date of purchase, at Brinly-Hardy Company's expense. Our obligation under this warrranty is expressly limited to replacement or repair, at our option of parts which are defective in material or workmanship within thirty (30) days of receipt of the parts. This warranty does not apply to damage caused by unreasonable use, including failure to provide necessary maintenance, nor does it apply to any transportation or labor charges.

WE MAKE NO OTHER EXPRESS WARRANTY NOR IS ANYONE AUTHORIZED TO MAKE ANY ON OUR BEHALF. ANY IMPLIED OR STATUTORY WARRANTIES, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. WE SHALL NOT BE LIABLE FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES OF ANY KIND.

BRINLY-HARDY COMPANY (502) 585-3351

MADE IN U.S.A.



PARTS LIST

STS-300 BH

REF	PART NO.	DESCRIPTION	QTY.	REF	PART NO.	DESCRIPTION
1	B-1673P	Hex Lock Nut- 1/4"	4	31	R-1806-10	Lower Tube
2	B-1674P	Hex Lock Nut- 5/16"	16	32	R-1807-10	Baffle
3	B-3385	Hex Lock Nut- #10	2	33	R-1808-10	Housing Assembly
4	B-3861	Hitch Pin- 1/2"x2 1/4"	1	34	R-1815	Hamper Rod
5	B-3718	Hex Lock Nut- 3/8"	2	35	R-1816-10	Hamper Support Bar
6	B-4676	Logo Decal	1	36	R-1818	Hamper Spacer
7	D-146P	Hair Pin Cotter	1	37	R-1825	Adjusting Knob
8	R-618	Special Washer- 5/16"	4	38	R-1827	Hamper & Wind Screen
9	R-644A-01	Frame Latch	2	39	R-1830	Brush Section
10	R-646	Latch Spring	2	40	R-1842-10	Tow Bar Support Tube
11	R-882-A	Drive Pinion	2	41	R-1844-10	Wheel Support Tube
12	R-892-10	Drawbar Clevis	2	42	R-1846-10	Handle Assembly
13	R-968-10	Rear Tube- Top & Bottom	2	43	R-1848-10	Tow Bar Assembly
14	R-970	Stop Rod	1	44	R-1856	Bronze Bearing
15	R-1012	Long Axle	1	45	1M0824P	Hex Bolt- 1/4"x1-1/2"
16	R-1013	Short Axle	1	46	2M0832P	Hex Bolt- 1/4"x2"
17	R-1014	Drive Pin	2	47	2M1012P	Hex Bolt- 5/16"x3/4"
18	R-1882	Handle Grip	1	48	2M1016P	Hex Bolt- 5/16"x1"
19	R-1039	Pull Rope	1	49	2M1020P	Hex Bolt- 5/16"x1-1/4"
20	R-1502	Machine Screw- #10 x 7/8"	2	50	10M1020P	Carriage Bolt- 5/16"x1-1/4"
21	R-1508	Brush holder Half	4	51	10M1032P	Carriage Bolt- 5/16"x2"
22	R-1523	Hex Screw- #10 x 1/2"	8	52	30M0600P	Hex Nut- #10
23	R-1584	Drive Gear	2	53	30M1200P	Hex Nut- 3/8"
24	R-1595	Shoulder Bolt- 1/2"	2	54	45M0909P	Flat Washer- 1/4"
25	R-1721	Height Adjust Decal	1	55	45M1111P	Flat Washer- 5/16"
26	R-1722	Pan Head Screw- 1/4" x 3/4"	6	56	45M1717P	Flat Washer- 1/2"
27	R-1723	Wheel & Tire Assembly	2	57	B-1675P	Hex Lock Nut-3/8"
28	R-1738-10	Dust Shield	2	58	R-1874	Instructions Decal
29	R-1805 R-10	Upper Tube- (R.H.)	1			
30	R1805 L-10	Upper Tube- (L.H.)	1			

L-1525-BH 7 PRINTED IN