



附件

DYM1668 Petrol Mower Part List

Modle No. :DYM1668

| Item | |
|---------------|-----------------------------------|
| GN-DYM1668-1 | 7 " wheel cover |
| GN-DYM1668-2 | Nut |
| GN-DYM1668-3 | axis |
| GN-DYM1668-4 | 7 " wheel assey |
| GN-DYM1668-5 | wave washer |
| GN-DYM1668-6 | front wheel axis assey |
| GN-DYM1668-7 | front wheel axis fixing steelwire |
| GN-DYM1668-8 | front wheel axis fixing ring |
| GN-DYM1668-9 | deck |
| GN-DYM1668-10 | connection rod spring |
| GN-DYM1668-11 | flat washer |
| GN-DYM1668-12 | connection rod |
| GN-DYM1668-13 | elastic open pin |
| GN-DYM1668-14 | 9 " dust protection wheel cover |
| GN-DYM1668-15 | left gear |
| GN-DYM1668-16 | Open block ring |
| GN-DYM1668-17 | 9 " wheel assey |
| GN-DYM1668-18 | 9 " wheel cover |
| GN-DYM1668-19 | Bolt |
| GN-DYM1668-20 | Bolt |
| GN-DYM1668-21 | Washer |
| GN-DYM1668-22 | Engine |
| GN-DYM1668-23 | bolt |
| GN-DYM1668-24 | Washer |
| GN-DYM1668-25 | cord protecting sheath |
| GN-DYM1668-26 | Bolt |
| GN-DYM1668-27 | left handle bar |
| GN-DYM1668-28 | long pole |
| GN-DYM1668-29 | Bearing clip |
| GN-DYM1668-30 | back cover spring |
| GN-DYM1668-31 | heat shrink tube |
| GN-DYM1668-32 | back cover |
| GN-DYM1668-33 | Bolt |
| GN-DYM1668-34 | Washer |
| GN-DYM1668-35 | elastic Washer |
| GN-DYM1668-36 | Nut |
| GN-DYM1668-37 | cable clip |
| GN-DYM1668-38 | lower handle bar |
| GN-DYM1668-39 | column pin |
| GN-DYM1668-40 | locking handle |
| GN-DYM1668-41 | press tighten plate |
| GN-DYM1668-42 | handle locking bolt |
| GN-DYM1668-43 | Nut |
| GN-DYM1668-44 | Bolt |
| GN-DYM1668-45 | accelerograph handle assey |
| GN-DYM1668-46 | driving cord assey |
| GN-DYM1668-47 | washer |
| GN-DYM1668-48 | elastic Washer |
| GN-DYM1668-49 | Nut |
| GN-DYM1668-50 | handle sheath |
| GN-DYM1668-51 | driving pulling rod |
| GN-DYM1668-52 | upper handle bar |
| GN-DYM1668-53 | frame pulling rod |
| GN-DYM1668-54 | flameout cord assey |
| GN-DYM1668-55 | Bolt |
| GN-DYM1668-56 | Cable hook |
| GN-DYM1668-57 | Grass bag |
| GN-DYM1668-58 | Grass bag support |

| | |
|---------------|-------------------------|
| GN-DYM1668-59 | right gear |
| GN-DYM1668-60 | Bearing |
| GN-DYM1668-61 | Bearing sheath |
| GN-DYM1668-62 | Screw |
| GN-DYM1668-63 | front wheel axis assey |
| GN-DYM1668-64 | handle sheath assey |
| GN-DYM1668-65 | Handle |
| GN-DYM1668-66 | Nut |
| GN-DYM1668-67 | right handle bar |
| GN-DYM1668-68 | Nut |
| GN-DYM1668-69 | adjustment board |
| GN-DYM1668-70 | Screw |
| GN-DYM1668-71 | Bolt |
| GN-DYM1668-72 | adjustment washer |
| GN-DYM1668-73 | open washer |
| GN-DYM1668-74 | axis clip |
| GN-DYM1668-75 | triangle Belt |
| GN-DYM1668-76 | driven wheel |
| GN-DYM1668-77 | column pin |
| GN-DYM1668-78 | Gear box pulling spring |
| GN-DYM1668-79 | Gear box assey |
| GN-DYM1668-80 | column pin |
| GN-DYM1668-81 | driving wheel |
| GN-DYM1668-82 | Screw |
| GN-DYM1668-83 | Screw |
| GN-DYM1668-84 | belt protecting cover |
| GN-DYM1668-85 | Screw |
| GN-DYM1668-86 | Flat key |
| GN-DYM1668-87 | Blade support |
| GN-DYM1668-88 | Blade |
| GN-DYM1668-89 | Washer |
| GN-DYM1668-90 | Bolt |
| GN-DYM1668-91 | Screw |
| GN-DYM1668-92 | wrench |
| GN-DYM1668-93 | wrench pole |

