


LCT

414CC SNOW ENGINE SERVICE KIT
PLMHK191150781DEABGIJOQVE1M/S
PW2HK191150781DEABGIJOQTUVE1M
PW2HK191150781DYABGIJOQTUVZ7



1	Heater Box Assembly-Snow	4100	29	Ignition Coil Assy	4690
3	Muffler Assembly-Snow	4200	30	Crankcase Cover Assy	4143600
4	Fuel Tank Assembly-Snow	4300	31	Black Oil Dipstick	4143711
5	Fuel Tank Cap-Oversized (Click Style)-Snow	4301	32	Charging Coil AC/DC	4141710
6	Carburetor Assembly-Snow	4302	33	Electric Starter Bracket	4405
8	Primer Bulb Assembly W/ Hose-Snow	4304	34	Spark Plug Boot	4691
10	Electric Starter Assembly-Snow	4400	36	Governor Link Assembly	4143000
10A	European 230V Electric Starter	4412	37	Governor Shaft	4143100
11	Key Switch Assembly-Snow	4401	38	Governor Gear Assembly	4142900
12	CDI Box Assembly-Snow	4404	39	Camshaft	4141600
13	On/Off Switch-Snow	4403	40	Cylinder Head Assy	4141050
15	Choke Knob-Snow	4500	41	Spark Plug	2911550
16	Governor Linkage Shield Plate-Snow	4501	42	CDI Box Bracket-Snow	4402
17	Recoil Starter Assembly-Snow	4600	44	Piston and Rod Assy	4141400
18	Starter Cup Small-Snow	4601	46	Vapor Shield	4606
19	Starter Grip-Snow	4603	47	Seal Kit	4143905
20	Blower Housing Assembly, Electric Start-Snow	4602	48	Wire Harness	4406
21	Shield, Cylinder	4141010	49	Crankshaft	4141800
22	Shield, Under Flywheel Charging System-Snow	4604	50	Top Shield	4141020
23	Valve Cover	4144500	51	Fuel Tank Skirt	4101
25	Fuel Petcock, Snow	4900	52	Rocker Arm Kit	4141100
26	Flywheel Assembly, Electric Start-Snow	4141701	53	Push Rod Tappet Kit	4141001
26A	Flywheel Assembly, Manual Start-Snow	4141700	54	Cylinder Assembly	4444
27	High Oil Fill Assy Kit, Snow	4911	55	Counter Weight Kit	4141650
28	Flywheel Fan	4144000	56	Engine Gasket Kit	4144300
			57	Fuel Hose Kit	4146000
			58	Extended Oil Drain Tube	4700
			61	Fuel Knob-Snow	4503
			62	Non-Removable Oil Plug	4143715
			63	CE Compliant Muffler Shield	4202
			64	Red Key Set	0407

rev. 11/16/10

■ Electric Start Only