


LCT

291CC SNOW ENGINE SERVICE KIT
PLMHK19850781 DEABGIJQQUVE1M/S
PW2HK19850781 DEABGIJQQTUVE1M
PW2HK19850781 DYABGIJQQTUVZE7M



1	Heater Box Assembly-Snow	2100	29	Ignition Coil Assy	4690
3	Muffler Assembly-Snow	4200	30	Crankcase Cover Assy	2913600
4	Fuel Tank Assembly-Snow	2300	31	Black Oil Dipstick	4143711
5	Fuel Tank Cap-Oversized (Click Style)-Snow	4301	32	Charging Coil AC/DC	4141710
6	Carburetor Assembly-Snow	2302	33	Electric Starter Bracket	4405
8	Primer Bulb Assembly w/ Hose-Snow	4304	34	Spark Plug Boot	4691
10	Electric Starter Assembly-Snow	2400	36	Governor Arm Assy	2502
10A	European 230V Electric Starter	2412	37	Governor Shaft	2913100
11	Key Switch Assembly-Snow	4401	38	Governor Gear Assembly	2912900
12	CDI Box Assembly-Snow	4404	39	Camshaft	2911600
13	On/Off Switch-Snow	4403	40	Cylinder Head Assy	2911000
15	Choke Knob-Snow	4500	41	Spark Plug	2911550
16	Governor Linkage Shield Plate-Snow	2501	42	CDI Box Bracket-Snow	4402
17	Recoil Starter Assembly-Snow	2600	44	Piston and Rod Assy	2911400
18	Starter Cup Small-Snow	2601	46	Vapor Shield	4606
19	Starter Grip-Snow	2603	47	Seal Kit	2913900
20	Blower Housing Assembly, Electric Start-Snow	2602	48	Wire Harness	4406
21	Shield, Cylinder	4141010	49	Crankshaft	2911800
22	Shield, Under Flywheel Charging System-Snow	4604	50	Top Shield	2911020
23	Valve Cover	4144500	51	Fuel Tank Skirt	2101
25	Fuel Petcock, Snow	4900	52	Rocker Arm Kit	4141100
26	Flywheel Assembly, Electric Start-Snow	2911701	53	Push Rod Tappet Kit	2911001
26A	Flywheel Assembly, Manual Start-Snow	2911700	54	Cylinder Assembly	2222
27	High Oil Fill Assy Kit, Snow	4911	56	Engine Gasket Kit	2914300
28	Flywheel Fan	2914000	57	Fuel Hose Kit	2916000
			58	Extended Oil Drain Tube	4700
			61	Fuel Knob-Snow	4503
			62	Non-Removable Oil Plug	4143715
			63	CE Compliant Muffler Shield	2202
			64	Red Key Set	0407

rev. 11/16/10

■ Electric Start Only