


# XMx P7P



## XMX P7P

	Télescopique lance with handle	R010mx
	Télescopique lance without handle	R01mx
	Safety valve	R03d
	Lance tip with nozzle MR1.5	Z12/15
	Feeding valve integrated with handle	R020j
	Complete pump	R05d
1	Container profession	R60 (B) (C) (D)
2	Pump cylinder	R19f
3	Container cap	R15
4	Piston half-case	R147
5	Pump nut	R12a
6	Pump piston	R20u
7	Lance pipe., fi 12mm	R73nx50
8	Lance pipe., fi 8mm	R73mx60
9	Clasp case, fi 8mm	R103
10	Feeding valve trigger	R44
11	Lance handle	R02j
12	Filter	R40
13	Hose end piston	R81e
14	Hose nut	R80e
15	Hose	R011d
16	Sucking pipe	M08_
17	Hose stub pipe	R82c
18	Safety valve body	R82d
19	Safety valve - shank	R98
20	Spring	R13n
21	Nut M-16	R26
22	Safety valve - handle	R100
23	Nozzle nucleus	R114
24	Nozzle nut	R64
25	Nozzle 1.5 nut for MR	R115_1.5
26	Piston	R43
27	Spring	R48a
28	Nut without hole	R50
29	Brass bar, fi 3mm	M11
30	Lance ring clasp	R107
31	Telescope ring faucet	R109
32	Clasp ring	R106
33	Seal 16x24	R17
34	Pump rubber valve-cap	R24
35	O-ring 38x5	R14
36	O-ring 28x4	R22
37	O-ring 11,3x2,4	R47c
38	O-ring 10x2	R41
39	O-ring 8x2	R108
40	O-ring 5,3x2	R116
41	O-ring 3x2	R42
42	O-ring 28x2	R22a