

# LED CORDLESS WORK LIGHT

LITHIUM-ION  TECHNOLOGY

**ITEM: 140007**  
**SL 175R - SL 175B**

BRUGERVEJLEDNING  
BENUTZERHANDBUCH  
OWNER'S MANUAL  
MANUAL DEL PROPIETARIO  
MANUEL D'UTILISATION  
MANUALE UTENTE  
GEBRUIKSHANDLEIDING  
BRUKSANVISNING



|    |       |       |    |       |       |
|----|-------|-------|----|-------|-------|
| DA | ..... | X - X | FR | ..... | X - X |
| DE | ..... | X - X | IT | ..... | X - X |
| EN | ..... | X - X | NL | ..... | X - X |
| ES | ..... | X - X | SV | ..... | X - X |

**PLEASE SAVE THIS OWNER'S MANUAL AND READ BEFORE EACH USE.**

This manual will explain how to use the work light safely and effectively. Please read and follow these instructions and precautions carefully.

**IMPORTANT:** Please read these instructions carefully. Note the safe operational requirements, warning & cautions. Use the product correctly and with care for the purpose for which it is intended. **FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.**

**1. IMPORTANT SAFETY INSTRUCTIONS****SAVE THESE INSTRUCTIONS.**

- 1.1 **SAVE THESE INSTRUCTIONS** – This manual contains important safety and operating instructions.
- 1.2 Read, understand and follow all instructions, cautions and warnings listed in this manual. Failure to follow all instructions and abide by all cautions and warnings could result in personal injury, injury to others and property damage.
- 1.3 **IMPORTANT! CHARGE WORK LIGHT IMMEDIATELY AFTER PURCHASE, AFTER EACH USE, AND AT LEAST EVERY 6 MONTHS.**
- 1.4 DO NOT turn on the work light while it is being charged.
- 1.5 DO NOT handle or move the work light while it is being charged.
- 1.6 DO NOT cover or block the lens during use.
- 1.7 DO NOT look directly into the light or shine the light directly into the eyes of any person or animal.
- 1.8 DO NOT allow children to use the work light.
- 1.9 DO NOT operate the work light if it has received a sharp blow, been dropped, or otherwise damaged in any way; take it to a qualified service person.
- 1.10 DO NOT leave the battery in a discharged state.
- 1.11 **WARNING!** Do not use any other chargers except the ones provided to charge the internal battery. Use of a charger not supplied by Schumacher® Electric Corporation may result in a risk of fire, injury to persons and/or damage to property.
- 1.12 DO NOT use the work light with a charger which has a damaged cord or plug, replace the cord or plug immediately.
- 1.13 **IMPORTANT!** Make sure the voltage marked on the charger plug is the same as the work light.
- 1.14 To reduce the risk of damage to the charger plug, pull by the plug, rather than the cord when disconnecting the charger.
- 1.15 DO NOT use the provided charger to charge or power any other electrical item.
- 1.16 DO NOT immerse the work light in water.
- 1.17 **AC CHARGER FOR INDOOR USE ONLY.** DO NOT expose the AC charger to water or use in damp conditions.
- 1.18 Ensure the work light is unplugged and allowed to cool before attempting any cleaning or replacement.

**2. PERSONAL SAFETY PRECAUTIONS****WARNING! TO REDUCE THE RISK OF BURNS OR FIRE, FOLLOW THESE SAFETY PRECAUTIONS:**

- 2.1 DO NOT open or disassemble the work light; take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire.
- 2.2 DO NOT crush, puncture, short external contacts or dispose of in fire or water.
- 2.3 DO NOT expose to temperatures above 140°F (60°C).
- 2.4 Replace the battery pack ONLY with one designed for this product.
- 2.5 Recycle or dispose of the used battery as required by local regulations. DO NOT dispose of with household waste.
- 2.6 If the electrolyte in the cells gets on your skin, wash thoroughly with soap and water. If it gets into your eyes, rinse thoroughly with cool water and seek immediate medical attention.
- 2.7 **This product contains a lithium ion battery.** In case of fire, you may use water, a foam extinguisher, Halon, CO<sub>2</sub>, ABC dry chemical, powdered graphite, copper powder or soda (sodium carbonate) to extinguish the fire. Once the fire is extinguished, douse the product with water, an aqueous-based extinguishing agent, or other nonalcoholic liquids to cool the product and prevent the battery from re-igniting. NEVER attempt to pick up or move a hot, smoking, or burning product, as you may be injured.

### 3. CHARGING

The battery fitted to this lamp is considered to be a consumable item and its ability to accept a charge will reduce over time. We will provide warranty against mechanical and electrical defect for a period of one year – this does not cover fair wear and tear. If the battery is not properly charged before first use, or regularly conditioned, its capacity will

diminish. Under these circumstances we will not replace the battery regardless of whether it is less than one year old.

Note: The lithium battery does not suffer from memory effect and once fully charged may be stored for up to six months without another charge.

### 4. OPERATING INSTRUCTIONS

- 4.1** Remove connection cover located on the rear of the light just below red on/off button. Connect charging lead to the socket in the back of light. Connect charger to power supply, switch on power supply. The battery will begin charging, full charge will be reached in approx. 4.5hrs. The three LED lights show the state of charge of the battery when the light is on. Switch off remove charger and replace cover. (A USB port is also position next to the charging connection so that the battery can be used as a powerbank.)
- 4.2** Direct the lens away from your eyes before switching on.
- 4.3** Press on/off button once for low, twice for medium and three times for high lumens output.
- 4.4** The lamp can swivel through 360° and be tilted.

### 5. MAINTENANCE INSTRUCTIONS

- 5.1** After use and before performing unplug and disconnect cleaning
- 5.2** Ensure the work light is unplugged and maintenance, allowed to cool before attempting any the work light
- 5.3** Any servicing should be performed by qualified service personnel.

### 6. TROUBLESHOOTING

| PROBLEM                          | POSSIBLE CAUSE              | SOLUTION   |
|----------------------------------|-----------------------------|--|
| The work light does not operate. | The battery is not charged. | Recharge the battery to full charge.                         |
|                                  | The battery may be bad.     | Have the battery replaced by a qualified service technician. |

### 7. BEFORE RETURNING FOR REPAIRS

For information about troubleshooting, contact: SCHUMACHER EUROPE- Rue de la Baronnerie, 3  
B-4920 Harzé - BELGIUM

info@ceteor.com - www.ceteor.com - Tel : +32.4.388.20.17

### 8. SPECIFICATIONS

|                                       |                   |
|---------------------------------------|-------------------|
| Battery .....                         | 7.4V 4.4Ah Li-ion |
| LED Quantity .....                    | 72 SMD            |
| Power .....                           | 36W               |
| Lumen Output (High/Medium/Low).....   | 3000/1500/750lm   |
| Operating Time (High/Medium/Low)..... | 1.5/2.5/5hr       |
| Colour Temperature.....               | 6500K             |
| Charging Time.....                    | 4.5hr             |
| IP Rating.....                        | IP65              |

## 9. LIMITED WARRANTY

**SCHUMACHER ELECTRIC CORPORATION, 801 BUSINESS CENTER DRIVE, MOUNT PROSPECT, IL 60056-2179, MAKES THIS LIMITED WARRANTY TO THE ORIGINAL RETAIL PURCHASER OF THIS PRODUCT. THIS LIMITED WARRANTY IS NOT TRANSFERABLE OR ASSIGNABLE.**

Schumacher Electric Corporation (the "Manufacturer") warrants this work light for two (2) year from the date of purchase at retail against defective material or workmanship that may occur under normal use and care. If your unit is not free from defective material or workmanship, Manufacturer's obligation under this warranty is solely to repair or replace your product with a new or reconditioned unit at the option of the Manufacturer. It is the obligation of the purchaser to forward the unit, along with proof of purchase and mailing charges prepaid to the Manufacturer or its authorized representatives in order for repair or replacement to occur. Manufacturer does not provide any warranty for any accessories used with this product that are not manufactured by Schumacher Electric Corporation and approved for use with this product. This Limited Warranty is void if the product is misused, subjected to careless handling, repaired, or modified by anyone other than Manufacturer or if this unit is resold through an unauthorized retailer. Manufacturer makes no other warranties, including, but not limited to, express, implied or statutory warranties, including without limitation, any implied warranty of merchantability or implied warranty of fitness for a particular purpose. Further, Manufacturer shall not be liable for any incidental, special or consequential damage claims incurred by purchasers, users or others associated with this product, including, but not limited to, lost profits, revenues, anticipated sales, business opportunities, goodwill, business interruption and any other injury or damage. Any and all such warranties, other than the limited warranty included herein, are hereby expressly disclaimed and excluded. Some states do not allow the exclusion or limitation of incidental or consequential damages or length of implied warranty, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights and it is possible you may have other rights which vary from this warranty. THIS LIMITED WARRANTY IS THE ONLY EXPRESS LIMITED WARRANTY AND THE MANUFACTURER NEITHER ASSUMES OR AUTHORIZES ANYONE TO ASSUME OR MAKE ANY OTHER OBLIGATION TOWARDS THE PRODUCT OTHER THAN THIS WARRANTY.

Schumacher® and the Schumacher logo are registered trademarks  
of Schumacher Electric Corporation.  
**Patent : PTC/gb2013/051234**

### Environmental Protection



Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain off any fluids (if applicable) into approved containers and dispose of the product and the fluids according to local regulations.

### WEEE Regulations



Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.

### Battery Removal



Remove the 6 hex screws on the back of the lamp. Remove the back casing. Remove the 4 screws holding circuit board and remove board. Remove 4 screws holding battery housing remove battery cells and disconnect wires. Dispose of according to local government guidelines.