


GARDEN SPREADER


Instruction Manual

BI5B15



ASSEMBLY

1. Fit spreader handle, connector tubes and elbows with screws. As shown.




2. Fix elbows on the bottom of tank with four screws.


3. Insert stirring assembly and rotating fan into stirring hole at the same time to connect them together.



4. Insert transmission shaft into big gear and elbow holes.




5. Push transmission bushing into elbow holes from two sides (chimb facing outward)




ASSEMBLY


6. Push two wheels into transmission shaft.



7. Cross two brackets through bracket clasps.



8. Long bracket fastens material tank and short bracket is used for elbows.



9. Screw control thread into threaded receiver.



OPERATING INSTRUCTIONS

For best result, adjust the spreading rate before you start.


- 1. Check the control wire is tightened with the threaded adjuster.**
- 2. Turn the spreading meter rating setting until the correct number is visible in magnifier.**
- 3. Commence walking, then squeeze the trigger to open the spreader.**

ALWAYS PUSH the spreader when applying contents . When pulled backward while open, the spreader may apply an excess amount of contents.












MAINTENANCE

- 1. Never leave contents in the spreader. Pour leftover material back into package and seal the package tightly.**
- 2. After use, wash thoroughly to remove all material in the spreader. Hot water may be required at times to remove stubborn residue. Allow the spreader to dry naturally**
- 3. Store the spreader in a clean dry place**

Note: this unit does not require lubrication.



PARTS LIST

1		2		3A		3B	
	2PC		1PC		1PC		2PC
4A		4B		5		6	
	1PC		8PC		1PC		1PC
7		8		9			
	1PC		2PC		2PC		

