



1	Clip de fixation	409588
2	Joint	410724
3	Conduit	410723
4	Vis	409534
5	Rondelle	409541
6	Joint torique	406094
7	Flasque de pompe	407596
8	Joint torique	406090
9	Bouchon	406089
10	Jeu de joints	409535
11	Joint	406818
12	Fermeture de diffuseur	409579
13	Carter Inox	409536
14	Ecrou	406822
15	Rondelle plate	406821
16	Turbine	407597
17	Diffuseur	406819
18	Rondelle	407598
19	Circlips	407599
20	Bobine	407600
21	Jeu de joints	409535
22	Corps de pompe	409543
23	Ecrou	700121
24	Ecrou	700150
25	Poignée	409544
26	Fermeture	409545
27	Vis	406116
28	Rondelle	409554
29	Ecrou	409546
30	Flasque	406103
31	NLA	NLA
32	Rotor	409537
33	NLA	NLA
34	Stator	406150
35	Joint	406110
36	Boîtier de connexions	409416
37	Condensateur 20 μ F	406149
38	Vis	406114
39	Boîtier de connexions	409416
40	Boîtier de connexions	409416
41	Rondelle	700959
42	Attache câble	406118
43	Vis	409578
44	Rondelle	700426
45	Bagues à lèvres	406122
46	Rondelle	703451
47	Ventilateur	406124
48	Protection PVC	406125
49	Vis	409590
50	Douille	406130
51	Douille	406130
52	Clapet soupape	409586
53	Soupape	406147
54	Vis	410422
55	Cuve / Réservoir	406146
56	Manomètre	406142



57	Joint torique	406094
58	Membrane	406145
59	Plaque	410722
60	Plaque	410722
61	Vis	407513
62	Plaque	410722
63	Joint torique	407511
64	Boîtier interrupteur	407510
65	Câble	407509
66	Câble de raccordement	406141
67		407587

