



LCT

GENII 208 SNOW ENGINE SERVICE KIT
PW2HK18650178EABGJOQVVE1M
PW2HK18650178ZABGOQVZE7M
PW2HK18650178YABGOQVZE7M



1	Heater Box Assembly-Snow	0102	29	Ignition Coil Assy	2082500
3	Muffler Assembly-Snow	0201	30	Crankcase Cover Assy	2083600
4	Fuel Tank Assembly-Snow	0311	31	Black Oil Dipstick	2083711
5	Oversized Fuel Tank Cap (Click Style)	0301	32	Charging Coil DC	0770
6	Snow Carburetor Assy	0312	34	Spark Plug Boot	4691
8	Fuel Primer Bulb with Hose	0304	36	Governor Arm Assy	2083000
10	Electric Starter Assy	0400	37	Governor Shaft	2083100
10A	European 230V Electric Starter	0412	38	Governor Gear Assy	2082900
11	Key Switch Assy	0401	39	Camshaft	2081600
12	CDI Box	0404	40	Cylinder Head Assy	2081000
13	On/Off Switch	0403	41	Spark Plug	2083810
15	Choke Knob-Snow	4500	42	CDI Box Bracket	0402
16	Governor Linkage Shield Plate	0501	44	Piston And Rod Assy	2081400
17	Recoil Starter Assembly-Snow	0600	46	Vapor Shield	0155
18	Starter Cup Small	0601	47	Seal Kit	2083900
19	Snow Starter Grip	0603	48	Wire Harness	0160
20	Blower Housing Assembly Electric Start - Snow (Black)	0602	49	Crankshaft	2081800
20A	Blower Housing Assembly Manual Start - Snow (Black)	0612	50	Speed Control Bracket	0150
21	Shield, Cylinder	0608	51	Fuel Tank Skirt	0103
22	Shield, Flywheel - Electric Start (If Equipped)	0605	52	Rocker Arm Kit	2081100
22A	Shield, Flywheel - Manual Start	0607	53	Push Rod Kit	2081001
23	Valve Cover	2084500	54	Cylinder Assembly	0001
25	Fuel Petcock, Snow	4900	56	Gasket Kit	2084300
26	Electric Start Flywheel Assy	0405	57	Fuel Hose Kit	2086000
26A	Manual Start Flywheel Assy	2081700	58	Extended Oil Drain Tube	0700
27	High Oil Fill Tube Assy	2083701	61	Fuel Knob - Snow	4503
28	Flywheel Fan	2084000	62	Non-Removable Oil Plug	2083705
			63	CE Compliant Muffler Shield	0202
			64	Red Key Set	0407



Electric Start Only

rev. 11/16/10