



SB4300RD & SB4300RDGY BROADCAST SPREADERS

3845

Parts List and Instructions





CUSTOMER SUPPORT

At Precision Products, Inc. delivering quality, value and outstanding service is our goal. However, sometimes parts do become damaged or lost during transport from our facilities to the store. If you have any problems, please do not return this merchandise to the store. Call us and we will take care of any problem you may have with this unit. Phone (800) 225-5891 Ext. 204


| HOW TO ORDER REPLACEMENT PARTS: | Send To: Parts Division 316 Limit Street Lincoln, IL 62656 | Retain for future reference Parts referenced with ** have two color options. | | | | | | | |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------|---------------------------------------------------------------------------------|--------|---------------------------|----------|------------------------------------------------------------------------------|-------|-----------------------------|-----|
| When ordering parts always give model number, part number and part description. | | Ref | Parts | Description | Qty | Ref | Parts | Description | Qty |
| | | No | No | | | No | No | - | |
| | Phone (800) 225-5891 (217) 735-1590 Ext. 204 | 1 | 2564B | Axle - 1/2" x 17" (Black) | | 12 | 1868 | 1/4" x 2-1/4" Carriage Bolt | 7 |
| | | ** | 2564G | Axle - 1/2" x 17" (Gray) | - | 13 | 1660 | I/4" x I-I/4" Hex Head Bolt | 2 |
| | FAX (217) 735-2435 | 2 | 2886 | Hopper | 1 | 14 | 1042 | Hitch Pin Clip | |
| | www.precisionprodinc.com | 3 | 2887 | Leg Stand (Black) | 1 | 15 | 1060 | Split Spacer | 2 |
| | ····· | ** | 2887G | Leg Stand (Gray) | | 16 | 1040R | Hub Cap | 2 |
| LIMITED WARRANTY This unit is warranted against defects in materials and workmanship to the original purchaser, under normal use and service, for a period of ninety (90) days from date of sale. During the Warranty Period, we will repair or replace at our option free of charge to the original purchaser, any part of the Unit that our examination shows to be defective in workmanship or materials. This Warranty Does Not apply to damage caused by misuse, abuse, neglect, accident, normal wear, or alterations by unauthorized persons. | | 4 | 2888B | Handle (Black) | 1 | 17 | 1842 | Split Bushing | 2 |
| | | ** | 2888GY | Handle (Gray) | | 18 | 1270 | I/4" Hex Head Nut | 6 |
| | | 5 | 2554 | Handle Cover | 1 | 19 | 2828 | Wing Nut | 3 |
| | | 6 | 2889G | Gear Case | $1 \sim$ | 20 | 1053 | 7/8" Tube Plug | 2 |
| | | 7 | 2890 | Wheel | 2 | TIP: Many of these hardware parts can be purchased at your local hard | | | |
| | | 8 | 2546B | Cross Brace (Black) | 1 | | | | |
| | | ** | 2546G | Cross Brace (Gray) | | | | | |
| | | 9 | 2892B | Hopper Support (Black) | 2 | | | | |
| | | | 2892G | Hopper Support (Gray) | | | | | |
| PRECISION PRODUCTS, INC. | | | 2441 | Cable Control | 1 | | | | |
| | | | 2614 | Spinner Disc | 1 | | | | |

06/05

USING YOUR SPREADER SB4300RD & SB4300RDGY Broadcast Spreader

STEP I

Un-fold Handle and tighten Wing Nuts.




FOR STORAGE



USING YOUR SPREADER

Settings are made by pressing down on the Calibration Indicator button and setting to desired number on the Control Cable Assembly.

Control Lever



* TO OPEN - Push the Control Lever forward until it stops against button.
* TO CLOSE - Pull the Control Lever fully back toward Operator.

See Application chart for setting information.

MAINTENANCE INSTRUCTIONS

AFTER EACH USE: Wash unit thoroughly let dry. Lubricate moving parts, including slide plate, axle and upright shaft.

CAUTION:

CARE MUST BE TAKEN WITH ANY WEED KILLER, PESTICIDE, OR COMBINATION PRODUCT. THEY CAN BE HARMFUL TO OTHER PLANT LIFE IN THE YARD.