

PS45SS

Ref#		Description	Ref#		Description
1	PS45SS-1	Handle Connecting Piece	37	PS45SS-37	Inner Axle Bushing
2	PS45SS-2	Semi-Circle Bolt M6X25	38	PS45SS-38	Outer Axle Bushing
3	PS45SS-3	Lock Washer Ø8	39	PS45SS-39	Gear
4	PS45SS-4	Gauge Plate Assembly	40	PS45SS-40	Small Gear
5	PS45SS-5	Adjust Handle	41	PS45SS-41	Screw M4X20
6	PS45SS-6	Adjusting Handle A	42	PS45SS-42	Impeller
7	PS45SS-7	Adjusting Handle B	43	PS45SS-43	Flat Washer Ø6
8	PS45SS-8	Screw Bolt	44	PS45SS-44	Nylon lock nut M5
9	PS45SS-9	Spacer	45	PS45SS-45	Cross Tube
10	PS45SS-10	Wing Nut	46	PS45SS-46	Connecting Rod B
11	PS45SS-11	Bolt M6x45	47	PS45SS-47	Bolt M6X65
12	PS45SS-12	Nylon Washer	48	PS45SS-48	Screen
13	PS45SS-13	Big Flat Washer Ø6	49	PS45SS-49	Spring Washer
14	PS45SS-14	Connecting Plate B	50	PS45SS-50	Bolt M6X55
15	PS45SS-15	Handle Foam	51	PS45SS-51	Rain Cover
16	PS45SS-16	Hopper	52	PS45SS-52	Vertical Axle
17	PS45SS-17	R pin Ø2x60	53	PS45SS-53	Roll Pin Ø3X16
18	PS45SS-18	Middle Spacer	54	PS45SS-54	Bolt M6X40
19	PS45SS-19	Pivot Bracket Assembly	55	PS45SS-55	Vertical Axle Bushing
20	PS45SS-20	Wheel Tube	56	PS45SS-56	Vertical Axle Fixing Plate
21	PS45SS-21	Nut M6	57	PS45SS-57	vertical Axle Fixing base
22	PS45SS-22	End Cap	58	PS45SS-58	Back Deflector
23	PS45SS-23	Handle Tube	59	PS45SS-59	Wing Nut M6
24	PS45SS-24	Nylon Lock Nut M6	60	PS45SS-60	Bolt M6X20
25	PS45SS-25	Connecting Rod A	61	PS45SS-61	Left Deflector
26	PS45SS-26	Handle Connecting Tube	62	PS45SS-62	Front Deflector
27	PS45SS-27	Adjustable Plate	63	PS45SS-63	Night Deflector
28	PS45SS-28	Big Flat Washer Ø4	64	PS45SS-64	Hanging Tube
29	PS45SS-29	Screw Bolt M4X12	65	PS45SS-65	Plate
30	PS45SS-30	Frame Tube	66	PS45SS-66	Roll Pin Ø4x30
31	PS45SS-31	Connecting Plate A	67	PS45SS-67	Bolt M5X40
32	PS45SS-32	Bolt M6x50	68	PS45SS-68	Wheel Axle
33	PS45SS-33	Bolt M6x35	69	PS45SS-69	Lock Washer Ø6
34	PS45SS-34	Flat Washer Ø16	70	PS45SS-70	Bolt M6X60
35	PS45SS-35	Bushing	71	PS45SS-71	Cotter Pin Ø5X35
36	PS45SS-36	Wheel	72	PS45SS-72	Cotter Pin Ø2X10

HARDWARE BAG