



REPAIR PARTS MANUAL MODEL NO. AY1236E Lawn Tractor



HOW TO USE THIS MANUAL

This manual is designed to provide the customer with a means to identify the parts on his/her tractor when ordering repair parts. The illustrations may or may not represent the actual assemblies; therefore, it is not recommended to use this manual as a guide to assemble or disassemble the tractor. Some hardware and parts are drawn larger in order to more readily identify them.

Each tractor has its own model number.

The model number for your tractor can be found on the fender under the seat.

When ordering parts, always give the following information:

- Product "Tractor"
- Model Number "AY1236E"
- Part Number
- Part Description

SPECIFICATIONS




TABLE OF CONTENTS

ELECTRICAL	4-5
HOOD	6
FENDER/CHASSIS	7
SEAT	
DASH	9
STEERING WHEEL	10
SECTOR GEAR/AXLE SUPPORT	
FRONT AXLE	12
BRAKE/REAR MOWER LIFT ASSEMBLY	13
ENGINE/THROTTLE	14
GROUND DRIVE	15
TRANSAXLE	16
MOWER LIFT LEVER	
MOWER DECK	
DECALS	

LIMITED WARRANTY

The Manufacturer warrants to the original consumer purchaser that this product as manufactured is free from defects in materials and workmanship. For a period of one (1) year from date of purchase by the original consumer purchaser, we will repair or replace, at our option, without charge for parts or labor incurred in replacing parts, any part which we find to be defective due to materials or workmanship. This Warranty is subject to the following limitations and exclusions.

- This warranty does not apply to the engine, other than FHP manufactured transaxle/transmission components, battery (except as noted below) or components parts thereof. Please refer to the applicable manufacturer's warranty on these items.
- 2. Transportation charges for the movement of any power equipment unit or attachment are the responsibility of the purchaser. Transportation charges for any parts submitted for replacement under this warranty must be paid by the purchaser unless such return is requested by Frigidaire Home Products.
- 3. Battery Warranty: On products equipped with a Battery, we will replace, without charge to you, any battery which we find to be defective in manufacture, during the first ninety (90) days of ownership. After ninety (90) days, we will exchange the Battery, charging you 1/12 of the price of a new Battery for each full month from the date of the original sale. Battery must be maintained in accordance with the instructions furnished.
- 4. The Warranty period for any products used for rental or commercial purposes is limited to 90 days from the date of original purchase.
- 5. This Warranty applies only to products which have been properly assembled, adjusted, operated, and maintained in accordance with the instructions furnished. This Warranty does not apply to any product which has been subjected to alteration, misuse, abuse, improper assembly or installation, delivery damage, or to normal wear of the product.
- 6. Exclusions: Excluded from this Warranty are belts, blades, blade adapters, normal wear, normal adjustments, standard hardware and normal maintenance.
- 7. In the event you have a claim under this Warranty, you must return the product to an authorized service dealer.

Should you have any unanswered questions concerning this Warranty, please contact:

Frigidaire Home Products
Outdoor Products Customer Service Dept.
250 Bobby Jones Expressway
Augusta, GA 30909 USA

In Canada contact:
Frigidaire Home Products
7075 Ordan Drive
Mississauga, Ontario
L5T 1K6


giving the model number, serial number and date of purchase of your product and the name and address of the authorized dealer from whom it was purchased.

THIS WARRANTY DOES NOT APPLY TO INCIDENTAL OR CONSEQUENTIAL DAMAGES AND ANY IMPLIED WARRANTIES ARE LIMITED TO THE SAME TIME PERIODS STATED HEREIN FOR OUR EXPRESSED WARRANTIES. Some areas do not allow the limitation of consequential damages or limitations of how long an implied Warranty may last, so the above limitations or exclusions may not apply to you. This Warranty gives you specific legal rights, and you may have other rights which vary from locale to locale.

This is a limited Warranty within the meaning of that term as defined in the Magnuson-Moss Act of 1975.

TRACTOR -- MODEL NUMBER AY1236E

ELECTRICAL



TRACTOR -- MODEL NUMBER AY1236E


ELECTRICAL

1 73640400 Nut, Hex, Keps 1/4-20 2 108423X Assembly, Cable 3 144924 Battery 4 69180 Nut, lock #10-24 UNC 5 108236X Bracket, Switch 6 109553X Switch, Interlock, 4 Terminal 7 146374 Keeper, Actuator 8 17021008 Screw, Hex Head, Self-Tapping #10-24 x 1/2 9 140401 Key, Molded 10 141226 Cover, Ignition Key 11 140400 Nut, Ignition 12 163088 Switch, Ignition 15 121305X Switch, Plunger 17 108824X Fuse 18 128353 Assembly, Cable 19 146064 Harness, Ignition 20 73350400 Nut, Hex, Jam 1/4-20 21 10090400 Washer, Lock 1/4 22 71110408 Bolt, Hex, Fin. 1/4-20 UNC x 1/2 Grade 5 24 131563 Cover, Terminal 25 145673 Solenoid 26 74760412 Bolt, Hex Head 1/4-20 UNC x 3/4 Nut keps Hex 1/4-20 UNC x 3/4 Nut keps Hex 1/4-20 UNC 3/4 Nut keps Hex 1/4-20 UNC 3/4	KEY		DECORIDATION
2 108423X Assembly, Cable 3 144924 Battery 4 69180 Nut, lock #10-24 UNC 5 108236X Bracket, Switch 6 109553X Switch, Interlock, 4 Terminal 7 146374 Keeper, Actuator 8 17021008 Screw, Hex Head, Self-Tapping #10-24 x 1/2 9 140401 Key, Molded 10 141226 Cover, Ignition Key 11 140400 Nut, Ignition 12 163088 Switch, Ignition 15 121305X Switch, Plunger 17 108824X Fuse 18 128353 Assembly, Cable 19 146064 Harness, Ignition 20 73350400 Nut, Hex, Jam 1/4-20 21 10090400 Washer, Lock 1/4 22 71110408 Bolt, Hex, Fin. 1/4-20 UNC x 1/2 Grade 5 24 131563 Cover, Terminal 25 145673 Solenoid 26 74760412 Bolt, Hex Head 1/4-20 UNC x 3/4 30 73510400 Nut keps Hex 1/4-20 Unc 31 4152J Bulb, Light	NO.	NO.	DESCRIPTION
2 108423X Assembly, Cable 3 144924 Battery 4 69180 Nut, lock #10-24 UNC 5 108236X Bracket, Switch 6 109553X Switch, Interlock, 4 Terminal 7 146374 Keeper, Actuator 8 17021008 Screw, Hex Head, Self-Tapping #10-24 x 1/2 9 140401 Key, Molded 10 141226 Cover, Ignition Key 11 140400 Nut, Ignition 12 163088 Switch, Ignition 15 121305X Switch, Plunger 17 108824X Fuse 18 128353 Assembly, Cable 19 146064 Harness, Ignition 20 73350400 Nut, Hex, Jam 1/4-20 21 10090400 Washer, Lock 1/4 22 71110408 Bolt, Hex, Fin. 1/4-20 UNC x 1/2 Grade 5 24 131563 Cover, Terminal 25 145673 Solenoid 26 74760412 Bolt, Hex Head 1/4-20 UNC x 3/4 30 73510400 Nut keps Hex 1/4-20 UNC 31 4152J Bulb, Light	1	73640400	Nut, Hex, Keps 1/4-20
8 17021008 Screw, Hex Head, Self-Tapping #10-24 x 1/2 9 140401 Key, Molded 10 141226 Cover, Ignition Key 11 140400 Nut, Ignition 12 163088 Switch, Ignition 15 121305X Switch, Plunger 17 108824X Fuse 18 128353 Assembly, Cable 19 146064 Harness, Ignition 20 73350400 Nut, Hex, Jam 1/4-20 21 10090400 Washer, Lock 1/4 22 71110408 Bolt, Hex, Fin. 1/4-20 UNC x 1/2 Grade 5 24 131563 Cover, Terminal 25 145673 Solenoid 26 74760412 Bolt, Hex Head 1/4-20 UNC x 3/4 30 73510400 Nut keps Hex 1/4-20 Unc 31 4152J Bulb, Light	2	108423X	
8 17021008 Screw, Hex Head, Self-Tapping #10-24 x 1/2 9 140401 Key, Molded 10 141226 Cover, Ignition Key 11 140400 Nut, Ignition 12 163088 Switch, Ignition 15 121305X Switch, Plunger 17 108824X Fuse 18 128353 Assembly, Cable 19 146064 Harness, Ignition 20 73350400 Nut, Hex, Jam 1/4-20 21 10090400 Washer, Lock 1/4 22 71110408 Bolt, Hex, Fin. 1/4-20 UNC x 1/2 Grade 5 24 131563 Cover, Terminal 25 145673 Solenoid 26 74760412 Bolt, Hex Head 1/4-20 UNC x 3/4 30 73510400 Nut keps Hex 1/4-20 Unc 31 4152J Bulb, Light	3		
8 17021008 Screw, Hex Head, Self-Tapping #10-24 x 1/2 9 140401 Key, Molded 10 141226 Cover, Ignition Key 11 140400 Nut, Ignition 12 163088 Switch, Ignition 15 121305X Switch, Plunger 17 108824X Fuse 18 128353 Assembly, Cable 19 146064 Harness, Ignition 20 73350400 Nut, Hex, Jam 1/4-20 21 10090400 Washer, Lock 1/4 22 71110408 Bolt, Hex, Fin. 1/4-20 UNC x 1/2 Grade 5 24 131563 Cover, Terminal 25 145673 Solenoid 26 74760412 Bolt, Hex Head 1/4-20 UNC x 3/4 30 73510400 Nut keps Hex 1/4-20 Unc 31 4152J Bulb, Light	4		
8 17021008 Screw, Hex Head, Self-Tapping #10-24 x 1/2 9 140401 Key, Molded 10 141226 Cover, Ignition Key 11 140400 Nut, Ignition 12 163088 Switch, Ignition 15 121305X Switch, Plunger 17 108824X Fuse 18 128353 Assembly, Cable 19 146064 Harness, Ignition 20 73350400 Nut, Hex, Jam 1/4-20 21 10090400 Washer, Lock 1/4 22 71110408 Bolt, Hex, Fin. 1/4-20 UNC x 1/2 Grade 5 24 131563 Cover, Terminal 25 145673 Solenoid 26 74760412 Bolt, Hex Head 1/4-20 UNC x 3/4 30 73510400 Nut keps Hex 1/4-20 Unc 31 4152J Bulb, Light	5		
8 17021008 Screw, Hex Head, Self-Tapping #10-24 x 1/2 9 140401 Key, Molded 10 141226 Cover, Ignition Key 11 140400 Nut, Ignition 12 163088 Switch, Ignition 15 121305X Switch, Plunger 17 108824X Fuse 18 128353 Assembly, Cable 19 146064 Harness, Ignition 20 73350400 Nut, Hex, Jam 1/4-20 21 10090400 Washer, Lock 1/4 22 71110408 Bolt, Hex, Fin. 1/4-20 UNC x 1/2 Grade 5 24 131563 Cover, Terminal 25 145673 Solenoid 26 74760412 Bolt, Hex Head 1/4-20 UNC x 3/4 30 73510400 Nut keps Hex 1/4-20 Unc 31 4152J Bulb, Light	6		
9 140401 Key, Molded 10 141226 Cover, Ignition Key 11 140400 Nut, Ignition 12 163088 Switch, Ignition 15 121305X Switch, Plunger 17 108824X Fuse 18 128353 Assembly, Cable 19 146064 Harness, Ignition 20 73350400 Nut, Hex, Jam 1/4-20 21 10090400 Washer, Lock 1/4 22 71110408 Bolt, Hex, Fin. 1/4-20 UNC x 1/2 Grade 5 24 131563 Cover, Terminal 25 145673 Solenoid 26 74760412 Bolt, Hex Head 1/4-20 UNC x 3/4 30 73510400 Nut keps Hex 1/4-20 Unc 31 4152J Bulb, Light	/		
10 141226 Cover, Ignition Key 11 140400 Nut, Ignition 12 163088 Switch, Ignition 15 121305X Switch, Plunger 17 108824X Fuse 18 128353 Assembly, Cable 19 146064 Harness, Ignition 20 73350400 Nut, Hex, Jam 1/4-20 21 10090400 Washer, Lock 1/4 22 71110408 Bolt, Hex, Fin. 1/4-20 UNC x 1/2 Grade 5 24 131563 Cover, Terminal 25 145673 Solenoid 26 74760412 Bolt, Hex Head 1/4-20 UNC x 3/4 30 73510400 Nut keps Hex 1/4-20 Unc 31 4152J Bulb, Light	8		
11 140400 Nut, Ignition 12 163088 Switch, Ignition 15 121305X Switch, Plunger 17 108824X Fuse 18 128353 Assembly, Cable 19 146064 Harness, Ignition 20 73350400 Nut, Hex, Jam 1/4-20 21 10090400 Washer, Lock 1/4 22 71110408 Bolt, Hex, Fin. 1/4-20 UNC x 1/2 Grade 5 24 131563 Cover, Terminal 25 145673 Solenoid 26 74760412 Bolt, Hex Head 1/4-20 UNC x 3/4 30 73510400 Nut keps Hex 1/4-20 Unc 31 4152J Bulb, Light			Cover Ignition Kov
12 163088 Switch, Ignition 15 121305X Switch, Plunger 17 108824X Fuse 18 128353 Assembly, Cable 19 146064 Harness, Ignition 20 73350400 Nut, Hex, Jam 1/4-20 21 10090400 Washer, Lock 1/4 22 71110408 Bolt, Hex, Fin. 1/4-20 UNC x 1/2 Grade 5 24 131563 Cover, Terminal 25 145673 Solenoid 26 74760412 Bolt, Hex Head 1/4-20 UNC x 3/4 30 73510400 Nut keps Hex 1/4-20 Unc 31 4152J Bulb, Light		_	Nut Ignition
15 121305X Switch, Plunger 17 108824X Fuse 18 128353 Assembly, Cable 19 146064 Harness, Ignition 20 73350400 Nut, Hex, Jam 1/4-20 21 10090400 Washer, Lock 1/4 22 71110408 Bolt, Hex, Fin. 1/4-20 UNC x 1/2 Grade 5 24 131563 Cover, Terminal 25 145673 Solenoid 26 74760412 Bolt, Hex Head 1/4-20 UNC x 3/4 30 73510400 Nut keps Hex 1/4-20 Unc 31 4152J Bulb, Light			
17 108824X Fuse 18 128353 Assembly, Cable 19 146064 Harness, Ignition 20 73350400 Nut, Hex, Jam 1/4-20 21 10090400 Washer, Lock 1/4 22 71110408 Bolt, Hex, Fin. 1/4-20 UNC x 1/2 Grade 5 24 131563 Cover, Terminal 25 145673 Solenoid 26 74760412 Bolt, Hex Head 1/4-20 UNC x 3/4 30 73510400 Nut keps Hex 1/4-20 Unc 31 4152J Bulb, Light			
18 128353 Assembly, Cable 19 146064 Harness, Ignition 20 73350400 Nut, Hex, Jam 1/4-20 21 10090400 Washer, Lock 1/4 22 71110408 Bolt, Hex, Fin. 1/4-20 UNC x 1/2 Grade 5 24 131563 Cover, Terminal 25 145673 Solenoid 26 74760412 Bolt, Hex Head 1/4-20 UNC x 3/4 30 73510400 Nut keps Hex 1/4-20 Unc 31 4152J Bulb, Light			
19 146064 Harness, Ignition 20 73350400 Nut, Hex, Jam 1/4-20 21 10090400 Washer, Lock 1/4 22 71110408 Bolt, Hex, Fin. 1/4-20 UNC x 1/2 Grade 5 24 131563 Cover, Terminal 25 145673 Solenoid 26 74760412 Bolt, Hex Head 1/4-20 UNC x 3/4 30 73510400 Nut keps Hex 1/4-20 Unc 31 4152J Bulb, Light			Assembly, Cable
21 10090400 Washer, Lock 1/4 22 71110408 Bolt, Hex, Fin. 1/4-20 UNC x 1/2 Grade 5 24 131563 Cover, Terminal 25 145673 Solenoid 26 74760412 Bolt, Hex Head 1/4-20 UNC x 3/4 30 73510400 Nut keps Hex 1/4-20 Unc 31 4152J Bulb, Light			
22 71110408 Bolt, Hex, Fin. 1/4-20 UNC x 1/2 Grade 5 24 131563 Cover, Terminal 25 145673 Solenoid 26 74760412 Bolt, Hex Head 1/4-20 UNC x 3/4 30 73510400 Nut keps Hex 1/4-20 Unc 31 4152J Bulb, Light			Nut, Hex, Jam 1/4-20
24 131563 Cover, Terminal 25 145673 Solenoid 26 74760412 Bolt, Hex Head 1/4-20 UNC x 3/4 30 73510400 Nut keps Hex 1/4-20 Unc 31 4152J Bulb, Light	21	10090400	
25 145673 Solenoid 26 74760412 Bolt, Hex Head 1/4-20 UNC x 3/4 30 73510400 Nut keps Hex 1/4-20 Unc 31 4152J Bulb, Light			
26 74760412 Bolt, Hex Head 1/4-20 UNC x 3/4 30 73510400 Nut keps Hex 1/4-20 Unc 31 4152J Bulb, Light			
30 73510400 Nut keps Hex 1/4-20 Unc 31 4152J Bulb, Light			
31 4152J Bulb, Light			
51 41920 Bub, Light	30 21		Nut keps Hex 1/4-20 Unc
32 136860 Harnace Dem Light	32	136850	Harness Asm. Light
33 110712X Switch, light, blk			
36 11150400 Washer, Lock, Internal Tooth 1/4			Washer, Lock, Internal Tooth 1/4
39 141735 Bracket Switch Clutch			
55 17490508 Screw Thdrol 5/16 - 18 x 1/2			
70 140413 Harness Engine			

NOTE: All component dimensions given in U.S. inches 1 inch = 25.4 mm

TRACTOR -- MODEL NUMBER AY1236E


HOOD



KEY	PART		KEY	PART	
NO.	NO.	DESCRIPTION	NO.	NO.	DESCRIPTION
1	124657X	Spring, Extension	9	73800400	Nut, Lock W/Insert 1/4-20
2	73510400	Nut, Hex, Keps 1/4-20 UNC	10	123693X	Brace, Hood
3	19091416	Washer 9/32 x 7/8 x 16 Ga.	11	132918X550	Hood
4	74780412	Bolt, Hex, Fin 1/4-20 x 3/4 Grade 5	12	122035X	Lens
5	139888	Bolt, Shoulder	13	127029X	Grill
6	122549X	Bracket, Hood, R.H.	14	4171R	Clip, line, fuel 11/32
7	122548X	Bracket, Hood, L.H.	18	19111116	Washer 11/32 x 11/16 x 16 Ga.
8	164863	Screw Hwhd Hi-Lo #13-16 x 3/4	NOT	E: All compone	ent dimensions given in U.S. inches

TRACTOR -- MODEL NUMBER AY1236E

FENDER / CHASSIS




KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	156417	Case, Battery	11	124346X	Nut, Self-Threading 3/16
2	19132012	Washer 13/32 x 1-1/4 x 12 Gauge	12	145190	Chassis, Assembly, Weldment
3	17490612	Screw, Hex Washer Head, Thd.	15	73640400	Nut, Hex, Keps 1/4-20
		Roll. 3/8-16 x 3/4	16	141736	Switch, Actuator
4	124181X	Spring, Compression, Seat	17	140782	Drawbar
5	127115X550	Plate, Battery	18	126470X	Clip, Insulated
7	124144X	Pad, Footrest	19	140955X550	Fender/Footrest
8	17490512	Screw, Hex Washer Head, Thd.	20	19091413	Washer 9/32 x 7/8 x 13 Gauge
		Roll. 5/16-18 x 3/4	25	17190516	ScrHx Wsh Thd Rol 5/16 - 18 x 1T
9	126997X428	Console, Shift Control	NOT	E. All compone	ant dimensione given in LLC inches
10	139783	Bar, Shift Lock	NOI	1 inch = 25	ent dimensions given in U.S. inches

NOTE: All component dimensions given in U.S. inches 1 inch = 25.4 mm.

TRACTOR -- MODEL NUMBER AY1236E


SEAT



KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	72050412	Bolt, Carriage 1/4-20 x 1-1/2	13	74780814	Bolt, Fin Hex 1/2 - 13 x 7/8 Gr. 5 Washer Lock Hvy HLCL Spr. 1/2 Washer 17/32 x 13/16 x 12 Gauge Bolt, Shoulder Bracket, Switch, Mounting Locknut, Hex, Large, Flange Bushing, Snap Spring, Compression Spacer, Split, Large .28 ld. x .96 onent dimensions given in U.S. inches 25.4 mm.
2	127426X	Seat	14	10040800	
3	155925	Pan, Seat	15	19171912	
4	73800500	Nut, Lock Hex W/Ins. 5/16-18	16	127018X	
5	153236	Bolt, Shld. 5/16-18	17	121246X	
6	145006	Clip, Push-In	18	123976X	
8	74760616	Bolt, Hex, Fin 3/8-16 UNC x 3/4	19	121248X	
9	140551	Bracket, Pivot, Seat	20	121250X	
11	19133210	Washer 13/32 x 2 x 10 Gauge	21	134300	
12	73800600	Nut, Lock Hex W/Wsh 3/8-16	NOT	TE: All compositions of the second	

TRACTOR - - MODEL NUMBER AY1236E

DASH




KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	141523	Cap, Fuel	12	3720R	Spring
2	138392	Assembly, Dash & Fuel Tank	13	126450X	Clip, Height Adjustment
3	123487X	Clamp, Hose	14	126115X	Knob, Height Stop
4	8544R	Line, Fuel	15	122023X	Adjustment, Quadrant Height
5	8548R	Line, Fuel	16	124346X	Nut, Self-Threading 3/16-18
6	73640400	Nut, Hex, Keps 1/4-20	17	72110404	Bolt, Carriage 1/4-20 x 1/2 Grade 5
7	2751R	Clip, Fuel Line	18	130745	Support Assembly, Dash
8	19091216	Washer 9/32 x 3/4 x 16 Gauge	19	134744	Brace, Cross
9	74760428	Bolt, Hex, Fin. 1/4-20 x 1-3/4	20	17060408	Screw, Tap 1/4-20 x 1/2
10	19091413	Washer 11/32 x 11/16 x 16 Gauge	21	134014	Plug, Dome
11	121249X	Spacer, Split			

NOTE: All component dimensions given in U.S. inches 1 inch = 25.4 mm.

TRACTOR -- MODEL NUMBER AY1236E


STEERING WHEEL



PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
133742	Insert, Steering Wheel	11	12000045	Ring, Retaining
10040600	Washer Lock, Hvy Hlcl 3/8	12	19211616	Washer 21/32 x 1 x 16 Ga.
19133808	Washer 13/32 x 2-3/8 x 8 Ga.	13	100711L	Adaptor, Steering Wheel
133741	Wheel, Steering	14	153720	Extension Shaft Steering
121897X	Sleeve, Steering	15	74780520	Bolt Fin Hex 5/16-18 UNC x 1-1/4
152927	Screw, TT #10-32 X 5 x 3/8 Flange	16	73800500	Nut Lock Hx W/Insert 5/16-18 UNC
155104	Bushing, Steering	17	74780616	Bolt, Fin hex 3/8-16 UNC x 1 Gr. 5
147391	Shaft, Steering	NOT	F: All compone	ent dimensions given in U.S. inches.
124210X	Clip, Steering			
123438X	Bushing, Lower, Steering		201	
	NO. 133742 10040600 19133808 133741 121897X 152927 155104 147391 124210X	NO. DESCRIPTION 133742 Insert, Steering Wheel 10040600 Washer Lock, Hvy Hlcl 3/8 19133808 Washer 13/32 x 2-3/8 x 8 Ga. 133741 Wheel, Steering 121897X Sleeve, Steering 152927 Screw, TT #10-32 X 5 x 3/8 Flange 155104 Bushing, Steering 147391 Shaft, Steering 124210X Clip, Steering	NO. DESCRIPTION NO. 133742 Insert, Steering Wheel 11 10040600 Washer Lock, Hvy Hlcl 3/8 12 19133808 Washer 13/32 x 2-3/8 x 8 Ga. 13 133741 Wheel, Steering 14 121897X Sleeve, Steering 15 152927 Screw, TT #10-32 X 5 x 3/8 Flange 16 155104 Bushing, Steering 17 147391 Shaft, Steering NOT 124210X Clip, Steering NOT	NO. DESCRIPTION NO. NO. 133742 Insert, Steering Wheel 11 12000045 10040600 Washer Lock, Hvy Hlcl 3/8 12 19211616 19133808 Washer 13/32 x 2-3/8 x 8 Ga. 13 100711L 133741 Wheel, Steering 14 153720 121897X Sleeve, Steering 15 74780520 152927 Screw, TT #10-32 X 5 x 3/8 Flange 16 73800500 155104 Bushing, Steering 17 74780616 147391 Shaft, Steering NOTE: All components of the components of

TRACTOR -- MODEL NUMBER AY1236E


SECTOR GEAR / AXLE SUPPORT



KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	132566	Link, Drag	10	76020412	Pin, Cotter 1/8 x 3/4
2	74780828	Bolt, Hex, Fin 1/2-13 x 1-3/4	11	19131316	Washer 13/32 x 13/16 x 16 Ga.
3	73680500	Nut, Crownlock 5/16-18	12	126847X	Bushing
4	73680600	Nut, Crownlock 3/8-16 UNC	13	74760512	Bolt, Hex 5/16-18 x 3/4
5	121926X	Gear, Sector	14	19111416	Washer 11/32 x 7/8 x 16 Ga.
6	121927X	Bushing	15	72110606	Bolt, Carriage 3/8-16 UNC x 3/4
7	73030800	Nut, Heavy, Hex, Top Lock 1/2-13 UNC	16	137096	Support, Front Axle
8 9	126472X 73680800	Clip, Wire Nut, Crownlock 1/2-13	NOT	E: All compone 1 inch = 25.	ent dimensions given in U.S. inches 4 mm.

TRACTOR - - MODEL NUMBER AY1236E


FRONT AXLE



KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	121232X	Cap, Spindle	11	126847X	Bushing
2	12000029	Ring, Klip	12	130465	Rod, Tie
3	121748X	Washer 25/32 x 1-5/8 x 16 Gauge	13	161827	Spindle Assembly, L.H.
4	3366R	Bearing	14	74011056	Bolt, Hex 5/8-11 x 3-1/2
5	142033	Axle, Front	15	73901000	Nut, Lock Flange 5/8-11
6	6266H	Bearing, Thrust	16	110438X	Spacer
7	161826	Spindle Assembly, R.H.	17	6855M	Fitting, Grease
8	121749X	Washer 25/32 x 1-1/4 x 16 Gauge	18	19272016	Washer 27/32 x 1-1/4 x 16 Ga.
9	76020412	Pin, Cotter 1/8 x 3/4	NOT	- All	(
10	19131316	Washer 13/32 x 13/16 x 16 Gauge	NOI	1 inch = 25	ent dimensions given in U.S. inches .4 mm.

TRACTOR - - MODEL NUMBER AY1236E


BRAKE / REAR MOWER LIFT ASSEMBLY



KEY	PART		KEY PAR	RT
NO.	NO.	DESCRIPTION	NO. NO.	. DESCRIPTION
1	71673	Cap, Parking Brake	17 12000	
2	123436X	Rod, Parking Brake	18 15133	
3	123437X	Bracket, Parking Brake	19 73350	0600 Nut, Hex Jam 3/8-16 UNC
4	8156H	Cover, Pedal	20 73800	Nut Lock Hex W/Insert 3/8-16 UNC
5	122504X	Bracket, Pedal, Clutch LH	21 13146	60 Rod, Rear Brake
6	76020312	Pin, Cotter 3/32 x 3/4	22 14458	35 Trunnion, Lift
7	19131016	Washer 13/32 x 5/8 x 16 Gauge	24 19132	2012 Washer 13/32 x 1-1/4 x 12 Gauge
8	17490508	Screw, Hex, Thd. Roll. 5/16-18 x 1/	25 4921H	H Spring, Retainer
		2	26 73930	0600 Nut, Čenterlock 3/8-16 UNC
9	76020412	Pin, Cotter 1/8 x 3/4	27 12736	59 Link, Threaded
10	19131316	Washer 13/32 x 13/16 x 16 Gauge	28 14077	76 Assembly, Rear Mower Lift
11	123543X	Rod, Front Brake	29 72110	
12	139933	Assembly, Clutch/Brake Pedal	30 73510	0500 Nut, Keps 5/16-18 UNC
13	123394X	Rod, Clutch	31 3146R	R Retainer, Spring
14	121978X	Bracket, Lift, Shaft	34 73680	0600 Nut, Crownlock 3/8-16
15	133332	Assembly, Brake, Pivot, Arm	NOTE: All o	component dimensions given in U.S. inches
16	19251816	Washer 25/32 x 1-1/8 x 16 Gauge		ich = 25.4 mm.

TRACTOR - - MODEL NUMBER AY1236E

ENGINE / THROTTLE




KEY	PART		KEY	PART	
NO.	NO.	DESCRIPTION	NO.	NO.	DESCRIPTION
1	17060408	Screw, Hex, Thread Cutting 1/4-20 x 1/2	11 12	137437	Bolt, Order from Engine Mfg. Muffler
2	133025	Control, Throttle	13	101326L	Deflector, Muffler
3		Engine, B&S, Model #289707	14	17030808	Screw, Spiderlock
4	71070512	Screw, Hex Hd	15	137180	Kit, Spark Arrester (Optional)
5	10040500	Washer, Lock, Heavy Helical Spring	16	127951	Stop, Choke
		5/16	17	17490624	Screw, Hex Washer Head, Thd.
6	165291	Gasket, Exhaust			Roll. 3/8-16 x 1-1/2
7	11050600	Washer Lock Ext Tooth 3/8	18	73510600	Nut Keps Hex 3/8-16
8	121094X	Bolt, Shoulder 5/16 UNC	19	2751R	Clip line fuel 13/32
9	19101216	Washer 5/16 x 3/4 x 16 Gauge	39	128861	Nut Flange 1/4-20
10	10040400	Washer, Lock, Hvv Hlcl Spring 1/4			3

NOTE: All component dimensions given in U.S. inches 1 inch = 25.4 mm

TRACTOR -- MODEL NUMBER AY1236E


GROUND DRIVE



KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	73680500	Nut, Lock Hex W/Ins 5/16-18	14	73930600	Nut, Centerlock 3/8-16 UNC
2	74760512	Bolt, Hex 5/16-18 UNC x 3/4	15	73680600	Nut, Crownlock 3/8-16
3	141342	Keeper, Mower Drive Belt, Engine,	16	126471X	Clip, Insulated
		R.H.	17	150932	Spacer, Retainer
4	138029	Pulley, Engine	18	131459	Spring, Extension
5	10040700	Washer, Lock, Heavy Helical Spring	19	73510500	Nut, Keps 5/16-18 UNC
		7/16	20	139919	Keeper, T/A Ground Drive Belt
6	71170744	Bolt, Hex, 7/16-20 x 2-3/4 Grade 5	21	19111016	Washer 11/32 x 5/8 x 16 Gauge
7	126520X	Traction, V-Belt Drive	22	123404X	Keeper, Ground Drive Belt, Frame
8	123405X	Keeper, T/A Ground Drive Belt	23	140916	Keeper, Mower Drive Belt, L.H.
9	72140612	Bolt, Carriage 3/8-16 UNC x 1-1/2	24	17720408	Screw, Thdcut 1/4-20 x 1/2
10	123396X	Keeper, Ground Drive Belt, Idler	25	150935	Bushing
11	150926	Arm, Ground Drive Clutch			
12	123674X	Idler, Flat	NOT	E: All compone	ent dimensions given in U.S. inches
13	19131316	Washer 13/32 x 13/16 x 16 Gauge		1 inch = 25.	

TRACTOR -- MODEL NUMBER AY1236E


TRANSAXLE



KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION	
NO.	NO.	DESCRIPTION	NO.	NO.	DESCRIPTION	
1	123385X	Pulley	20	19091210	Washer 9/32 x 3/4 x 10 Gauge	
2	12000028	Ring, Retainer	21	126292X	Arm, Shift	
3		Transaxle (See Breakdown)	22	105701X	Washer, Shift Plate	
		Peerless 205-507B	23	106933X	Knob, Deluxe	
4	2228M	Key, Woodruff #9	24	128215	Rod, Shift	
5	73680500	Nut, Lock Hex 5/16-18	25	76020416	Pin, Cotter 1/8 x 1	
6	72140506	Bolt, Carriage 5/16-18 UNC x 3/4	26	73810500	Nut, Hex, Nylon 5/16-24 UNF	
7	123378X	Strap, Torque	28	128085	Spring, Extension	
8	17490512	Screw 5/16-18 x 3/4	29	128084	Support, Handle, Shift, R.H.	
9	146682	Spring, Brake	31	137057	Spacer, Split	
10	121749X	Washer 25/32 x 1-1/4 x 16 Gauge	35	12000001	E-Ring E-Ring	
11	123583X	Key, Square	36	17720408	Screw, Thdcut. 1/4-20 x 1/2	
15	19171616	Washer 17/32 x 16 Ga.	38	74490540	Bolt, Hex, Flgnd 5/16-18	
16	124600X	Support, Handle Shift				
17 126293X Link, Shift						
18	74550412	Bolt, Hex, Fin 1/4-28 UNF x 3/4 Gr. 8	ТОИ		ent dimensions given in U.S. inches	
19	10040400	Washer, Lock 1/4	1 inch = 25.4 mm .			

TRACTOR - - MODEL NUMBER AY1236E

MOWER LIFT LEVER




KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	126470X	Clip, Insulated	16	4921H	Retainer, Spring
2	122018X	Bracket, Mower Clutch	17	127359	Link, Front Lift
3	71110408	Bolt, Hex, Fin 1/4-20 UNC x 1/2	18	142028	Trunnion, Threaded 3/8-16
		Grade 5	19	73680400	Nut, Crownlock 1/4-20
4	73680600	Nut, Crownlock 3/8-16	20	74760644	Bolt, Hex, Fin. 3/8-16 UNC x 2-3/4
5	145187	Assembly, Clutch Lever	23	76020416	Pin, Cotter 1/8 x 1
6	106451X	Bolt, Shoulder	24	19171612	Washer 17/32 x 1 x 16 Gauge
7	135371	Assembly, Mower Clutch Arm	25	121933X	Tube, Spacer
8	74760636	Bolt, Hex 3/8-16 UNC x 2-1/4	26	141470	Rod, Mower Lift
9	121930X	Assembly, Bellcrank, Lift	27	106932X	Knob, Rd
10	76020412	Pin, Cotter 1/8 x 3/4	28	76020312	Pin, Cotter 3/32 x 3/4
11	19131316	Washer 13/32 x 13/16 x 16 Gauge	29	131655	Link, Mower Clutch
12	131861	Sleeve, Handle	30	73350600	Nut, Hex Jam 3/8-16
13	139352	Assembly, Lift Handle	31	19132012	Washer 13/32 x 1-1/4 x 12 Ga.
14	123496X	Spring, Compression			
15	19131212	Washer 13/32 x 3/4 x 12 Gauge	NOT	E: All compone	ent dimensions given in U.S. inches

1 inch = 25.4 mm.

TRACTOR -- MODEL NUMBER AY1236E

MOWER DECK




TRACTOR -- MODEL NUMBER AY1236E

MOWER DECK

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	140064	Spring, Mower Clutch	30	136631	Bracket, Deflector
2	122052X	Spacer, Retainer	31	17490508	Screw, Hex Washer Head, Thd.
3	73680600	Nut, Crownlock 3/8-16			Roll. 5/16-18 x 1/2
4	130840	Assembly, Brake	32	122051X	Arm, Support Idler, Mower
5	131251	Guide, Belt Idler	33	131560	Shield, Deflector
6	121316X	Idler, Flat	36	121980X	Rod, Hinge
7	72110616	Bolt, Carriage 3/8-16 x 2 Grade 5	37	123713X	Spring, Torsion Deflector
8	19131410	Washer 13/32 x 7/8 x 10 Gauge	38	105304X	Cap, Sleeve
9	127744	Assembly, Mower Idler Arm	39	19111016	Washer 11/32 x 5/8 x 16 Gauge
10	72140610	Bolt, Carriage 3/8-16 x 1-1/4	40	110452X	Nut, Push
11	130841	Rod, Brake	41	131264	V-Belt
12	127356	Bracket, Rear Lift, R.H.	42	19171616	Washer 11/32 x 5/8 x 16 Gauge
13	72140506	Bolt, Carriage 5/16-18 UNC x 5/8	43	3146R	Clip, Hairpin
14	73680500	Nut, Crownlock 5/16-18	44	140608	Keeper, L.H.
15	127357	Bracket, Rear Lift, L.H.	45	110485X	Bearing
16	153298	Keeper, R.H.	46	128774	Housing, Mandrel, Vented
17	128508	Stabilizer, Mower Link	47	129895	Bearing
18	128511	Pin, Drive	48	137645	Shaft, Mandrel (Includes Key
19	127380	Bracket, Stabilizer Link	4.0	100010	Number 47)
20	138496	Blade, Mwr 36 High Lift	49	133943	Washer, Hardened
21	140296	Washer, Hard Blade Mower Vented	62	153390	Washer Felt
22	10030600	Washer, Lock, Heavy 3/8		130794	Mandrel Assembly (Includes Key
23	850857	Bolt 3/8-24 x 1-1/4 Grade 8		450000	Numbers 21-23, 26, 29 and 45-48)
24	140329	Stripper		156866	Deck, Serv 36 HP
25	157722	Screw, Thdrol. Washer Hd.			
27	156600	Housing, Mower	NOT	- All	and disconnicus since in H.C. is the
28	153531	Pulley, Mandrel	NOI		nent dimensions given in U.S. inches
29	137266	Nut, Flangelock 9/16		1 inch = 25	0.4 (1)(1).


TRACTOR -- MODEL NUMBER AY1236E

DECALS



KEY NO.	PART NO.	DESCRIPTION	KEY NO.
1	159739	Decal, Brake/Clu. Sym	13
2	126860X	Decal, Lightbox	14
3	161952	Decal, Hood, R.H.	15
4	161953	Dcal, Hood L.H.	16
5	136830	Decal, V-Belt Sch.	18
6	159736	Decal, Chassis	
7	145498	Decal, Read Owner's Manual Sym	
8	145494	Decal, Cutfinger Sym	
9	161950	Decal, Fender	
10	141517	Decal, Deck, Mower	Availa
12	145005	Decal, Caution, Battery	
		•	

TIRES & WHEELS



KEY NO.	PART NO.	DESCRIPTION
13	161951	Decal, Insert, Steering
14	126187X	Decal 100 Dba
15	165285	Decal, Engine
16	162598	Decal Drawbar Load Limit
18	145437	Decal, Europe, Stand, CE
	138311	Decal, Handle, Lift
	157065	Manual, Operator's (Euro)
	157216	Manual, Operator's (Scan)
	166967	Manual, Repair Parts
Avail	able accessorie	es are not included with your tractor:
	C36	Rear Bagger
	MK36	Mulcher Kit

KEY NO.	PART NO.	DESCRIPTION	
	59192 65139	Cap, Valve Stem, Valve	
3	65139 278H	Fitting, Grease (Front Only)	
	137422 132703	Tire, Front Tire, Rear	
5	59904	Tube, Tire, Front	
	8134H	(Optional, Service Item Only) Tube, Tire, Rear	
6	137237X	(Optional, Service Item Only) Rim Assembly, Front	
O	140325X		
7	104757X	Cap, Axle	
8 9	9040H 121748X	Bearing, Flange (Front Only) Washer, Axle Cap	
	144334	Sealant, Tire (10 oz. Tube)	

NOTE: All component dimensions given in U. S. inches 1 inch = 25.4 mm



SERVICE POLICY



WARRANTY

Issued January 1980 Revised January 1991

LIMITED WARRANTIES FOR NEW PEERLESS GEAR POWER TRAIN COMPONENTS

A. Products Warranted

Peerless Gear and Machine Division of Tecumseh Products Company ("Tecumseh"), subject to the limitations contained below, will, at its option, repair or replace, without charge for parts or labor only, any part of a new Power Train Component (which as used herein means and includes the transaxle, gear box, transmission, differential and right angle drives, and any part of the Power Train Component), EXCEPT any new Power Train Component incorporated in equipment used for commercial or rental purposes, which is found upon examination by any Tecumseh Authorized Service Outlet or by Tecumseh's factory in Grafton, Wisconsin, to be DEFECTIVE IN MATERIAL AND/OR WORKMANSHIP if received by Tecumseh or a Tecumseh Authorized Service Outlet for such examination within TWO YEARS from the date of sale to the original consumer purchaser of Peerless Series 820, 900, 910, 915, 920, 930 transaxles and Series 1100 angle drive and ONE YEAR for all other Peerless products. New Power Train Components incorporated in equipment used for NINETY (90) DAYS ONLY, and must be received by Tecumseh or by a Tecumseh Authorized Service Outlet for such examination within 90 days from the date of sale to the original purchaser. New Power Train Components Incorporated in equipment used for THIRTY (30) DAYS ONLY, and must be received by Tecumseh Authorized Service Outlet within 30 days from the date of sale to the original purchaser.

B. Products And Items Not Warranted

- 1. Alterations or Modifications of Power Train Components.
- 2. Accidents, Normal Maintenance, Failure to follow the Original Equipment Manufacturer's Manual.

This warranty covers only parts of new Power Train Components which are found upon examination to be defective in material or workmanship as delivered to the original purchaser. This warranty does not cover defects caused by depreciation or damage caused by normal wear, accidents, improper maintenance, improper use or abuse of the product, failure to follow the instructions contained in an Instruction Manual for the operation of the Power Train Component and parts. The cost of normal maintenance and replacement of service items which are not defective shall be paid for by the original purchaser.

C. Securing Warranty Service

Warranty service can be arranged for by contacting either a Tecumseh Authorized Service Outlet (any Tecumseh Registered Service Dealer, Tecumseh Authorized Service Distributor, or Tecumseh Central Warehouse Distributor) or by contacting Tecumseh, c/o Service Manager, Engine and Transmission Group Service Division, 900 North Street, Grafton, Wisconsin 53024. Warranty service can only be performed by a Tecumseh Authorized Service Outlet or by Tecumseh at its factory in Grafton, Wisconsin. At the time of requesting warranty service, evidence must be presented of the date of sale to the original purchaser. The purchaser shall pay any charges for making service calls and/or for transporting the product to and from the place where the inspection and/or warranty work is performed. The purchaser shall be responsible for any damage or loss incurred in connection with the transportation of Power Train Components and/or part(s) of the Power Train Components submitted for inspection and/or warranty work.

D. Limitation of Damages and Implied Warranties


The foregoing EXPRESSED WARRANTY IS IN LIEU OF ALL OTHER EXPRESS WARRANTIES. Neither Tecumseh nor any of its affiliates makes any warranties, representations or promises, written or oral, as to the quality of the Power Train Component or any of its parts, other than as set forth herein.

ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, TO THE EXTENT THAT EITHER MAY APPLY TO ANY PART(S) OF POWER TRAIN COMPONENTS, SHALL BE LIMITED IN DURATION TO THE PERIODS OF THE EXPRESSED WARRANTIES DEFINED IN PARAGRAPH A HEREOF. IN NO EVENT WILL TECUMSEH BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES AND/OR EXPENSES. Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitation(s) or exclusion(s) may not apply to you. This warranty gives you specific legal rights and you may also have other legal rights which vary from state to state.

E. No Dealer Warranty

Tecumseh neither assumes nor authorizes any other person, natural or corporate, to assume for Tecumseh any other obligations or liabilities in connection with or with respect to any part(s) of a Power Train Component. The seller or dealer of part(s) of a Power Train Component has no authority, whatsoever, to make any representations or promises on behalf of Tecumseh or to modify the terms or limitations of Tecumseh's warranty in any way.

SERVICE NOTES



SERVICE NOTES

