


REPAIR PARTS MANUAL MODEL NO. BM4TDEA Lawn Mower

BESTGREEN

ROTARY MOWER MODEL NO. BM4TDEA




2

ROTARY MOWER MODEL NO. BM4TDEA

KE NO		DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
	4 128638 5 51793 7 145669 9 156445X479 9 700363X479 1 46143X479 8 147613 5 151588X479 7 150078 9 750085X007 1 46630 2 700331X004 8 87877 4 145935X004 5 62335 6 142748 7 148438 8 83923 9 77400	Lower Handle Rope Guide Locknut 1/4-20 Handle Bolt Cable Tie Hex Washer Head Screw 1/4-20 x 2.12 Combi Key Control Drive Control Wing Nut Hairpin Cotter Drive Cable Guide Back Plate Side Baffle Foot Guard Rear Door Assembly Kit Handle Bracket Assembly (Left) Handle Bracket Assembly (Right) Screw 5/16-18 x 3/4 Wheel Adjusting Bracket Spacer Selector Spring Selector Knob	55 56 57 64 65 67 68 70 72 73 74 75	53998 54583 133188X479 850999 145494 850988 700063X479 165545 167730 851084 850263 851074 145106 851514 111190X 83816 147270 750532 150050 128415 751152 88652 751592 158755 122147X 167728 167729 800197 145495 161057	Flat Washer Hex Tapping Screw 1/4-20 x 1/2 Discharge Baffle Hex Head Thread Rolling Screw 3/8-16 x 2 Danger Decal Engine Spacer Rear Baffle Front Baffle Kit Housing Assembly (Incl. Ref. #46) Hex Head Bolt 3/8-24 x 1-3/8 Grd. 8 Helical Lock Washer Hardened Washer 20" Blade Blade Adapter Clamp Screw Grass Bag Catcher Frame * Engine - Briggs Model 12H887 Order parts from engine manufacturer Hex Washer Head Screw #10-16 x .50 Pop Rivet Nut Screw Nut Screw Key Operator's Manual (Euro) Replacement Parts Manual (English/French) Noise Level Decal International Symbols Decal Warning Decal (Not Shown)


ROTARY LAWN MOWER - - MODEL NO. BM4TDEA



ROTARY LAWN MOWER - - MODEL NO. BM4TDEA

	KEY NO.	PART NO.	DESCRIPTION	NO:		DESCRIPTION
	1	141912	Hex Washer Head Screw #10-24 x 1/2	21	152018	Adjuster Assembly (Left)
	2	154049	Drive Cover	22	152019	Adjuster Assembly (Right)
	3	701477	Pushin Fastener	24	88080	Dust Cover
	4	164795	Drive Pawl	25	67725	Washer
	5	88043	Drive Pulley	27	750124	Wheel & Tire Assembly
	6	12000030	Retaining Ring	28	145212	Flanged Locknut
	7	54583	Screw 1/4-20 x 1/2	29	85179	Retainer Clip
		851947X004	Clutch Frame	30	77400	Hubcap
	9	50962	Locknut 1/4-20	31	12000058	E-Ring
	10	702631X004	Clutch Lever	32	137054	Pinion
	11	88067	Clutch Lever Spacer	33	63601	Locknut 1/4-20
	12	750253	Locknut 5/16-18	34	700537	Drive Shaft
	13	72070504	Carriage Bolt 5/16-18 x 1/2	35	88082	Driven Pulley
	14	74350424	Hex Head Screw 1/4-20 x 1-1/2	36	111924X	Drive Belt
5		88069	Spacer		852000	"Clean Under" Decal (Drive Cover)
		48160	Idler Assembly (Includes Key No. 17)			
		88576	Idler Spacer	Avai	lable accessori	es not included with mower:
		88517	Shoulder Bolt 5/16-18 x 1-3/8		MA36	Chute Deflector
	19	88516	Idler Pulley		MK20FRD	Mulcher
	20	87877	Selector Knob			

ROTARY MOWER MODEL NUMBER BM4TDEA



KE NO		DESCRIPTION
1 2	157553 750909	Battery Box Battery
3	17411312	Hex Washer Head Screw
4	86353	13 x .750 Connector Mounting Clip
5	130024	Battery Charger

LIMITED WARRANTY

The Manufacturer warrants to the original consumer purchaser that this product as manufactured is free from defects in materials and workmanship. For a period of two (2) years from date of purchase by the original consumer purchaser, we will repair or replace, at our option, without charge for parts or labor incurred in replacing parts, any part which we find to be defective due to materials or workmanship. This Warranty is subject to the following limitations and exclusions.

- 1. This warranty does not apply to the engine. Please contact your nearest Bricomarché dealer where they will send the machine to the engine manufacturer.
- 2. Transportation charges for the movement of any power equipment unit or attachment are the responsibility of the purchaser. Transportation charges for any parts submitted for replacement under this warranty must be paid by the purchaser unless such return is requested by Bricomarché.
- 3. Battery Warranty: On products equipped with a Battery, we will replace, without charge to you, any battery which we find to be defective in manufacture, during the first ninety (90) days of ownership. After ninety (90) days, we will exchange the Battery, charging you 1/12 of the price of a new Battery for each full month from the date of the original sale. Battery must be maintained in accordance with the instructions furnished.
- 4. The Warranty period for any products used for rental or commercial purposes is limited to 45 days from the date of original purchase.
- 5. This Warranty applies only to products which have been properly assembled, adjusted, operated, and maintained in accordance with the instructions furnished. This Warranty does not apply to any product which has been subjected to alteration, misuse, abuse, improper assembly or installation, delivery damage, or to normal wear of the product.
- 6. Exclusions: Excluded from this Warranty are belts, blades, blade adapters, normal wear, normal adjustments, standard hardware and normal maintenance.
- 7. In the event you have a claim under this Warranty, please contact your nearest Bricomarché dealer.

Should you have any unanswered questions concerning this Warranty, please contact:

SERVICE CONSOMMATEURS BP443 91164 LONGJUMEAU cedex France

giving the model number, serial number and date of purchase of your product and the name and address of the authorized dealer from whom it was purchased.

THIS WARRANTY DOES NOT APPLY TO INCIDENTAL OR CONSEQUENTIAL DAMAGES. ANY IMPLIED WARRANTIES ARE LIMITED TO THE SAME TIME PERIODS STATED HEREIN.

This is a limited Warranty within the meaning of that term as defined in the Magnuson-Moss Act of 1975.

SPECIFICATIONS

