



Supplementary Manual



IMPORTANT! Instructions for Auto-Switching Charger

Charging Instructions:

1. Connect the charger to battery
2. Plug in the charger to power source.
3. Press the RESET button for **3 seconds** to start charging. LED will now turn RED.
4. Unplug the charger when LED turns GREEN.
5. Repeat the above steps for every recharging.

NOTE: when the LED on the CHARGER blinks (RED/GREEN), it indicates that either

3. battery has been overdischarged and will not be charged fully. Unplug the charger and recharge the battery again after 12 hours. Repeat this step will help vitalize your battery again.
4. the charging connections has been disturbed. Restart the charging instructions and make sure the connections are not loose.

WARNING!

- **BEFORE THE FIRST USE**, charge the battery until the LED turns GREEN.
- If the product is not in use for a while, it is also recommended to recharge
- the battery pack **ONCE EVERY THREE MONTHS**, this will contribute to a long battery life.
- **BATTERY MUST BE RECHARGED AFTER EACH USE!** A battery will last longer if charged as soon as it is used.
- **DO NOT DISCHARGE COMPLETELY AS THIS WILL DAMAGE THE BATTERY!**