

图 1







Fig.8 GUIDE BAR, SAW CHAIN, TOOLS



	NAME PN4500
GN4500-1	CYLINDER
GN4500-2	BOOT-INTAKE
GN4500-3	GASKET-INTAKE
GN4500-4	SCREW TX M5x14
GN4500-5	EYELET-CARBURETOR
GN4500-6	SUPPORT CARBURETOR
GN4500-7	SCREW TX M5x14
GN4500-8	FLANGE-CARBURETOR
GN4500-9	GASKET-CARBURETOR
GN4500-10	GASKET-CYLINDER
GN4500-11	SCREW TX M5x20
GN4500-12	BOLT M5x85-MUFFLER
GN4500-13	NUT M5
GN4500-14	MUFFLER
GN4500-15	SCREW TX M5x10
GN4500-16	GASKET-MUFFLER
GN4500-17	SHIELD-MUFFLER
GN4500-19	PIN D.6
GN4500-20	BEARING-BALL 35-15
GN4500-21	SNAP RING d35
GN4500-22	SEAL OIL
GN4500-23	SEAL OIL
GN4500-24	STUD-BAR M8
GN4500-25	HOSE-PULSE(ASSY)
GN4500-26	BUMPER-RUBBER(REAR RIGHT)
GN4500-27	BUMPER-RUBBER(REAR LEFT)
GN4500-28	GASKET-CRANK CASE
GN4500-29	SCREW TX M5x35
GN4500-30	HOSE-PULSE
GN4500-31	SPRING-HOSE PULSE
GN4500-32	GASKET-SUPPORT CARB
GN4500-33	PISTON
GN4500-34	RING-PISTON
GN4500-35	PIN-PISTON D11x34
GN4500-36	RING -SNAP D11
GN4500-37	BEARING-NEEDLE CONROD
GN4500-38	WASHER-SPACER PISTON
GN4500-39	CRANK SHAFT-CONROD ASSY
GN4500-40	KEY-FLYWHEEL
GN4500-41	FLY-WHEEL-ASSY
GN4500-42	PAWL-STARTER
GN4500-43	SPRING-PAWL
GN4500-44	RING-SNAP D5(PAWL)
GN4500-45	MUT M8-FLYWHEEL

GN4500-46	WASHER-SPRING D8,5/13,5
GN4500-47	ELECTRONIC IGNITION
GN4500-55	SCREW TX M5x20
GN4500-58	WIRE-SWITCH
GN4500-59	SWITCH-STOP ASSY
GN4500-60	SWITCH-STOP
GN4500-61	GROMMET-RUBBER(SWITCH)
GN4500-62	RETAINER SWITCH
GN4500-63	SCREW TX M5x10
GN4500-64	SPARK PLUG
GN4500-65	PLATE
GN4500-66	SCREW TX M4x6
GN4500-67	STARTER ASSY
GN4500-68	HOUSING-STARTER
GN4500-69	GROMMET-OUTER
GN4500-70	PULLEY-STARTER AXLE
GN4500-71	PULLEY-STARTER
GN4500-72	SPRING-STARTER(WITH GASE)
GN4500-73	ROPE-STARTER
GN4500-74	HANDLE-STARTER
GN4500-75	ROPE SNAP
GN4500-78	WASHER D5,5/16
GN4500-79	SCREW M5x20
GN4500-83	SCREW TX D5x14
GN4500-84	LABEL
GN4500-85	HANDLE-FRONT
GN4500-86	SCREW TX D5x16
GN4500-91	FUEL TANK ASSY
GN4500-92	LATCH-TRIGGER
GN4500-93	SPRING-THROTTLE ADVANCE
GN4500-94	BUTTON-THROTTLE ADVANCE
GN4500-95	BUMPER-RUBBER(FRONT)
GN4500-96	SCREW TX M4x12
GN4500-97	WASHER-RUBBER D3,5/8,5
GN4500-98	TRIGGER
GN4500-99	SPRING-TRIGGER
GN4500-100	PIN-TRIGGER D6x30
GN4500-101	LEVER-SAFETY TRIGGER
GN4500-102	COVER-REAR HANDLE
GN4500-103	SCREW TX D4,8x16
GN4500-104	CHAIN CATCHER
GN4500-105	SCREW TX M5x14
GN4500-106	PAD-RUBBER CUSHIONING(LOWER)
GN4500-107	SCREW TX D5x16
GN4500-108	PLUG-PAD
GN4500-109	SPRING-DAMPING

GN4500-110	RING-PLASTIC
GN4500-111	PAD-RUBBER CUSHIONING(UPPER)
GN4500-112	SCREW TX D5x16
GN4500-113	PLUG-PAD
GN4500-114	COVER- TOP YELLOW
GN4500-116	SCREW
GN4500-117	LABEL
GN4500-118	COVER- AIR FILTER YWLLOW
GN4500-119	KNOB-AIR FILTER
GN4500-120	GASKET-KNOB
GN4500-121	FILTER
GN4500-122	SPONGE FILTER
GN4500-123	SCREW
GN4500-124	GROMMET-FILRER
GN4500-125	FILTER-AIR
GN4500-126	LABEL
GN4500-127	BOOT-CARBURATOR
GN4500-128	GROMMET-OUTER
GN4500-129	GROMMET-INNER
GN4500-130	CAP-RUBBER
GN4500-131	SCREW
GN4500-132	CHOKE KNOB
GN4500-133	COVER- AIR FILTER YWLLOW
GN4500-134	CHOKE KNOB
GN4500-135	ROD-THROTTLE
GN4500-136	GASKET-RUBBER
GN4500-138	HOSE-FUEL
GN4500-139	GASKET-HOSE
GN4500-140	OIL FILTER
GN4500-146	CAP ASSY-FUEL
GN4500-147	GASAKE-FUEL CAP
GN4500-149	HOSE-OIL
GN4500-150	FILTER OIL
GN4500-151	CONNECTOR-OIL OUTLET
GN4500-152	VALVE-VENT
GN4500-153	FILTER VENT
GN4500-154	RING-SNAP
GN4500-156	OIL PUMP
GN4500-157	GEAR-WORM
GN4500-158	SEAL-FOAM
GN4500-159	SCREW
GN4500-160	COVER-OIL PUMP
GN4500-161	SCREW
GN4500-162	DRUM ASSY CLUTCH
GN4500-163	WASHER-CLUTCH
GN4500-164	CLUTCH ASSY
GN4500-165	SPRING CLUTCH

GN4500-166	BEARING-NEEDLE
GN4500-167	DRUM-CLUTCH
GN4500-168	SPROKET
GN4500-169	SPIKE
GN4500-170	SCREW
GN4500-171	PLATE-BAR
GN4500-172	SCREW
GN4500-173	PAD RUGHT
GN4500-174	NUT
GN4500-175	BRAKE HOUSING ASSY
GN4500-176	BRAKE HOUSING
GN4500-177	BUMPER-BRAKE HOUSING
GN4500-178	SCREW CHAIN ADJUSTING
GN4500-179	TOOTH-CHAINADJUSTING
GN4500-180	SPROCKET-CHAIN ADJUSTING
GN4500-181	PLATE-BAR
GN4500-182	PAD-RIGHT
GN4500-183	SCREW
GN4500-184	STRAP-RUBBER
GN4500-185	LEVER-CHAIN BRAKE
GN4500-186	PIN
GN4500-187	RING-SNAP
GN4500-188	SPRING-BRAKE LEVER
GN4500-189	PIN-LEVER
GN4500-190	BUSHING
GN4500-191	WASHER
GN4500-192	RING-SNAP
GN4500-193	PLATE-BRAKE
GN4500-194	WASHER-RUBBER
GN4500-195	COVER BRAKE
GN4500-196	SCREW
GN4500-197	LEVERAGE-BRAKE
GN4500-198	PLATE-BRAKE
GN4500-199	BAND-BRAKE
GN4500-200	PIN
GN4500-201	SPRING-ACTUATION
GN4500-202	SPRING-ACTUATION
GN4500-203	LABEL
GN4500-204	
GN4500-BAR 18" -1	GUIDE BAR--18"