


PARTS LIST

Ref#	Description	Qty		Ref#	Description
PS36-1	Carriage Bolt M6x25	1		PS36-25	Lock Nut M6
PS36-2	Lock Washer Ø8	1		PS36-26	Support Leg
PS36-3	Gauge and Lever Assembly	1		PS36-27	Wheel Assembly Frame(Right)
PS36-4	Adjust Handle Pole	1		PS36-28	Thin Washer
PS36-5	Adjust Handle A	1		PS36-29	Pneumatic Wheel
PS36-6	Adjust Handle B	1		PS36-30	Flat Washer Ø16
PS36-7	Screw M4x18	1		PS36-31	Axle End Cover
PS36-8	Handle Grip	1		PS36-32	Inner Axle Bushing
PS36-9	Spacer	1		PS36-33	Outer Axle Bushing
PS36-10	Wing Nut M6	1		PS36-34	Gear Box & Axle Assemble
PS36-11	Hopper	1		PS36-35	Screw M4x20
PS36-12	R Pin Ø2x60	1		PS36-36	Bolt M5x45
PS36-13	Center Cover	1		PS36-37	Line Clamp Press Plate
PS36-14	Bolt M6x65	4		PS36-38	Control Rod
PS36-15	Rivet Ø5X12	1		PS36-39	Screw M5x10
PS36-16	Active Adjustable Plate	3		PS36-40	Nylon Washer
PS36-17	Fixed Adjustable Plate	3		PS36-41	Big Flat Washer Ø6
PS36-18	Wheel Assembly Frame(Left)	1		PS36-42	Handle
PS36-19	Impeller	1		PS36-43	Fixing Connection Rod
PS36-20	Bolt M6x35	3		PS36-44	Big End Cap
PS36-21	Lock Nut M5	3		PS36-45	Small End Cap
PS36-22	Line Clamp Bottom Plate	1		PS36-46	Lock Washer Ø6
PS36-23	Tube End Cap	4		PS36-47	Hopper Screen
PS36-24	Bolt M6x40	6		PS36-48	Screw M5x12
				PS36-49	Rain Cover

hardware bags +manual

A



Qty	
12	
1	
1	
1	
2	
1	
2	
2	
2	
1	
1	
1	
1	
1	
2	
1	
5	
1	
1	
1	
2	
1	
1	

1set	
------	--