Precision Pro Steel Lawn Roller



SAFETY GUIDELINES FOR USE OF PRODUCT

- *The most important information is knowing how to stop your riding mower or lawn tractor, read your equipment's owner's manual for horse power and towing weights
- *With increased towing weight, your stopping distance increases also
- *Do not tow the roller up or down steep ditches or hills. Be extremely cautious around steep grades
- *Watch for holes, uneven terrain and other possible obstacles
- *Inspect roller and all hardware periodically. Be sure all parts are secure before and during operation
- *Never carry any passengers with you
- *Do not operate lawn roller on slopes greater than 10 12 degrees

USING YOUR LAWN ROLLER

- *Remove the expansion plug by loosening the wing nut.
- *Fill your roller with water or sand to recommended weight for your towing equipment (mower or lawn tractor). DO NOT GO OVER YOUR TOWING EQUIPMENT'S WEIGHT LIMIT. Failure to do so can result in damage to the towing equipment and/or personal injury.
- *Replace the expansion plug and tighten the wing nut. Make sure the plug is tight enough to stop any leakage.
- *Your lawn should be moist for best rolling conditions. Excessive water or muddy conditions are not recommended.
- *Keep your mower or lawn tractor at a safe and steady speed. 3 4 MPH is a good speed for proper operation.
- *Damage to your mower, lawn tractor and/or personal injury can occur if you start or stop the roller (filled) abruptly.
- *When finished using the roller, drain and let the interior fully dry. Never leave water in the lawn roller during cold weather. Freezing can occur, damaging the welded seams causing leaks and/or structural failure.

WEIGHT CAPACITIES PER MODEL

It is extremely important to know how much your mower or lawn equipment is designed to tow. Below are <u>approximate</u> weight capacities for individual models.


Model RL1836	Weight filled with water 33 lbs.	Weight filled with sand 530 lbs
RL2436	588 lbs.	942 lbs.
RL2448	784 lbs.	1,257 lbs.

MAINTENANCE

- *Always check all the hardware before use. Make sure all hardware and components are tight and secure.
- *Always keep moving joints lubricated. Lubricate the Clevis Assembly and Axle/Bearings when needed.
- *Keeping the roller clean and dry will prolong the unitis life.
- *Sand off any rust that might occur, and paint exposed metal with a quality enamel paint.

LIMITED WARRANTY

This unit is warranted against defects in materials and workmanship to the original purchaser, under normal use and service, for a period of ninety (90) days from date of sale. During the Warranty Period, we will repair or replace at our option free of charge to the original purchaser, any part of the Unit that our examination shows to be defective in workmanship or materials. This Warranty **Does Not** apply to damage caused by transit, misuse, abuse, neglect, accident, normal wear, or alterations by unauthorized persons.



PLEASE DO NOT RETURN THIS MERCHANDISE TO THE STORE. CALL US AND WE WILL TAKE CARE OF ANY PROBLEM YOU MIGHT HAVE WITH THIS PRODUCT. Phone (800) 225 - 5891 EXT. #204

RL1836 Parts List				RL2436 Parts List				RL2448 Parts List			
Ref	Parts	Description	Qty	Ref	Parts	Description	Qty :	Ref	Parts	Description	Qty
No				. No	No			No	No		
<u> </u>	1961A	Roller Body	1	1.1	2003A	Roller Body	1 :	1	1960A	Roller Body	11 :
2	2576	3/16î x 2î Cotter Pin	2 ;	2	2576	3/16î x 2î Cotter Pin	2 :	2	2576	3/16î x 2î Cotter Pin	2
; 3	2351	Iî Flat Washer	4 :	: 3	2351	Iî Flat Washer	4	; 3	2351	Iî Flat Washer	4
; 4	1955	Roller Bearing	2 :	4	1955	Roller Bearing	2	; 4	1955	Roller Bearing	2
; 5	1964	Hitch Side Bar	2	5	1964	Hitch Side Bar	2	; 5	1965	Hitch Side Bar	2
: 6	1974	3/8î x Iî Hex Head Bolt	4	6	1974	3/8î x Iî Hex Head Bolt	4	: 6	1974	3/8î x 1î Hex Head Bolt	4 ;
. 7	3039	3/8î Reverse Lock Nut	4	; 7	3039	3/8î Reverse Lock Nut	4 :	: 7	3039	3/8î Reverse Lock Nut	4 :
8	1966	Long Brace	1	; 8	1966	Long Brace	1 :	8	1967	Long Brace	11 :
. 9	1968	Short Brace	1 ;	: 9	1968	Short Brace	1 :	9	1969	Short Brace	11 }
10	1988	3/4î x 4î Hex Head Bolt	1 :	: 10	1988	3/4î x 4î Hex Head Bolt		10	1988	3/4î x 4î Hex Head Bolt	11 1
; 11	1264	3/4î Flat Washer	2 :	11	1264	3/4î Flat Washer	2	111	1264	3/4î Flat Washer	2
: 12	4279	Clevis Pin 5/8î x 3-1/2î		12	4279	Clevis Pin 5/8î x 3-1/2î	11 :	; 12	4279	Clevis Pin 5/8î x 3-1/2î	11 :
: 13	1989	3/4îLock Nut	1	13	1989	3/4îLock Nut	T	; 13	1989	3/4îLock Nut	1 :
14	1042	#14 Hitch Pin Clip	1 :	: 14	1042	#14 Hitch Pin Clip	1 1	: 14	1042	#14 Hitch Pin Clip	1 :
: 15	1972	Clevis Assembly	1 :	; 15	1972	Clevis Assembly	1 :	15	1972	Clevis Assembly	1 :
16	1956	Expansion Plug	<u> </u>	16	1956	Expansion Plug		16	1956	Expansion Plug	

<u>HOW TO ORDER</u> REPLACEMENT PARTS:

When ordering parts always give model number, part number and part description.

Send To: Parts Division 316 Limit Street Lincoln, IL 62656 Phone (800) 225-5891

(217) 735-1590 Ext. 204

FAX (217) 735-2435